Set Up and Operating Instructions for Remote Control Model R550

To setup the remote:

Direct Entry method:

Press and hold CODE SEARCH until the red lights stays on. Press and release TV, VCR, CBL, AUX, AUX1, AUX2, or AUX3. Enter the three digit code for your TV, VCR, etc., from the code list.

Code Search method:

Manually turn on the device you want to control (TV, VCR, etc.).

Press and hold CODE SEARCH until the red light stays on.

Press TV, VCR, CBL, etc.

Press the power button repeatedly until the device turns off. This may take up to 300 tries.

When the device turns off, press MUTE to complete the setup.

If you skip past the code (i. e, press power again after the device turns off) press CHANNEL DOWN to go back.

Operation:

You do not need to aim the remote at anything. The remote transmits wireless Radio Frequency (RF) commands to the RF to IR converter, Model P550 which converts the command back to Infrared (IR) commands to control your TV, VCR, Cable Box, etc.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

This equipment generates and uses radio frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturers instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for remote control security devices in accordance with the specifications in Sub-Part B of Part 15 of *FCC Rules*, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by unplugging the equipment, try to correct the interference by one or more of the following measures.

- o Reorient the antenna of the radio/TV experiencing the interference.
- o Relocate the product with respect to the radio/TV.
- o Move the product away from the radio/TV.
- o Plug the product into an outlet on a different electrical circuit from the radio/TV experiencing the interference. If necessary, consult your local dealer for additional suggestions.

NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.