

Transmitter

- 1) Open case to reveal 10 position DIP switch and Reed switch terminal
- 2) Set Code (1-8)
 - a) Set the first eight switch positions on S1
 - i) Code must match the code set on the receiver S1
- 3) Select door number transmitter is mounted on
 - a) Set S1-9 and S1-10 using table 2.

S1-9	S1-10	Door Number
On	On	3
Off	On	2
On	Off	1

Table 2.

- 4) Mount transmitter in safe location
- 5) Press and release Test Button on transmitter
 - a) This will sync the transmitter and receiver

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.