


Transmit Freq. range: 924.8~927.5 MHz
 Receive Freq. range: 902.2~904.9 MHz

Tx VCO Freq. : 914.1~916.8 MHz
 Rx VCO Freq. : 912.9~915.6 MHz

Crystal Freq. : 4.000 MHz



Sakura CD Controller Block Diagram
(Revision 0.10)