

# **Great Wall**


W710 User Guide

# Congratulation on your purchase and welcome to Greatwall Your Table pc




# Assembling and Charge

Insert TF card



Charge the Battery



## \* Tips:

- You can use the Table pc while it is charging.
- Keeping the charger plugged to the Table pc when the battery is fully charged will not damage the battery.
- If a fully charged battery left unused, it will lost its charge over time.
- If a battery is being used for the first time or the battery has not been used for a prolonged period, it may take longer time to recharge.






# Use your Table pc

## Turn your Table pc on and off

- 1 Press and hold power key to turn on your Table pc.
- 2 To turn off your Table pc, press and hold power key and then select **Power off**.

## Keys

Learn about the main keys.

Key	Definition	Function
	Power	Press and hold to power on/off. Press to turn on/off the screen display. Hold to access the Table pc options, choose Power off, Airplane mode or Restart.
	Home key	Return to the home screen. Hold to open the list of recent applications.
	Option key	Open a list of options available on the current screen. On the home screen, open the list of recent applications.
	Back key	Return to the previous screen or exit.
	Side volume key	Adjust the ringer volume while in standby mode or adjust the voice volume during a call. When receiving an incoming call, briefly press down either volume key to mute the ringtone.

## Home screen

From the Home screen, you can view your device's status and access applications.

The Home screen has multiple panels. Scroll left or right to view the panels on the Home screen.

## Notifications panel


When you get a new notification, you can open the Notifications panel to see what event notification or new information you have received.

- To open the Notifications panel, press and hold the status bar, then slide one finger downward. If you have several notifications, you can scroll down the screen to see them all.
- To hide the panel, drag the bottom of the panel upwards.

## Access applications

- Scroll left or right to another screen, select an application.
- Press ◀ to return to the previous screen, press □ to return to the Home screen.

## Manage applications

- In idle screen, tap **Settings**  >**Apps**.
- Tap **Running**, you can view all the running apps, tap this app to enter it, you can tap **Stop** to choose stop running.
- Tap **Downloaded**, you can view all the downloaded apps, tap app to enter it, you can check the detailed information of this app, tap **Uninstall** to unloading it.

## WIFI Connection

Your MID can be connected onto Wi-Fi network:

- 1 On the homepage interface, click and select the menu key and pop up the menu setting;
- 2 Click and select the System Setting;
- 3 Click Wi-Fi and open wi-fi switch;
- 4 After opening Wi-Fi, the Wi-Fi network can be scanned automatically from the equipment in the windows on the right.
- 5 Select the Wi-Fi network required to be connected, if the password is added, pop up the password input windows and input the corresponding password.
- 6 Click the Connection

 Note:

- Copyright protected pictures and sound cannot be sent by MMS.

# Safety & Precaution

## Precaution

### Keep your Table pc away from small children



Keep your Table pc and all accessories out of the reach of small children. Small parts may cause choking or serious injury if swallowed.

### Switch off your Table pc...



Turn off the Table pc when in an aircraft. The use of Table pc in an aircraft may be dangerous for the operation of the aircraft, disrupt the Table pc network and may be illegal.



In hospitals, clinics, other health care centers and anywhere else where you may be in the close vicinity of medical equipment.



In areas with a potentially explosive atmosphere (e.g. petrol stations and also areas where the air contains dust particles, such as metal powders). In a vehicle transporting flammable products or a vehicle powered by liquefied petroleum gas (LPG). In quarries or other areas where blasting operations are in progress.

### Your Table pc and your car



Avoid using your Table pc while driving and obey all regulations that restrict the use of Table pc while driving. Use hands free accessories to increase your safety when possible. Ensure that your Table pc and car kit do not block any air bags or other security devices fitted in your car.

### Handle your Table pc carefully and sensibly



For the optimal and satisfactory operation of the Table pc you are recommended to use the Table pc in the normal operating position.

- Do not expose your Table pc to extreme temperatures.
- Do not immerse the Table pc in any liquid; if your Table pc is damp, switch it off,
- To clean the Table pc, wipe it with a soft cloth.
- In hot weather or after prolonged exposure to the sun (e.g., behind a window or a wind screen), the temperature of your Table pc's casing might increase. Be very careful in this case when picking up your Table pc and also avoid using it with an ambient temperature over 40°C or under -10°C.

### Protect batteries from damage



You should only use Manufacturer Authentic Accessories, as the use of any other accessories may damage your Table pc and may be dangerous, and will make all guarantees for your Greatwall Table pc null and void.

Make sure damaged parts are replaced immediately by a qualified technician and that they are replaced with genuine manufacturer replacement parts.

- Your Table pc is powered by a rechargeable battery.
- Use specified charger only.
- Do not incinerate.
- Do not open back cover, Do not open back cover and touch battery.

- Avoid exposure to excessive cold or heat (under -15°C or over 55°C), moisture or caustic environments.

### Environmental care



Remember to observe the local regulations regarding the disposal of the packaging materials, exhausted batteries and old Table pc and please promote their recycling. Manufacturer has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.



The labeled packaging material is recyclable.



A financial contribution has been made to the associated national packaging recovery and recycling system.



The plastic material is recyclable (also identifies the type of plastic).

### Hearing Protection



When listening to music, adjust the volume to a moderate level.

Continuous exposure to high volume may impair your hearing. It is recommended to keep it away from your body and head at least 15mm during operation.

### Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

### Safety Information and Notices

Failure to comply with the following precautions may be dangerous or illegal.

Never attempt to disassemble your device. You alone are responsible for how you use your device and any consequences of its use.

As a general rule, always switch off your device wherever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.

Do not use your device in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.

Do not expose your device to extreme temperatures lower than - 10°C and higher than + 40°C.

Do not leave your device within the reach of small children (certain removable parts may be accidentally ingested). Please carefully read and observe the terms below:



### Distance of operation

This device model has been tested and meets radiofrequency exposure guidelines when used as follows:

- Against the ear: Place or receive a device call and hold the device as you would a wire line telephone.
- Body worn: When transmitting, place the device in a carry accessory that contains no metal and positions the device a minimum of 1.0cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the device at the ear, position the device a minimum of 1.0cm from your body,
- Data operation: When using a data feature, position the Table pc a minimum of 1.0 cm from your body for the whole duration of the data transmission.

### Adapter

Adapter shall be installed near the equipment and shall be easily accessible.

### Sound pressure safety

Use carefully with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.



### Caution

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

### Proper use

As described in this manual, your device can be used only in right location. If possible, please do not touch the antenna area on your device.

## Tips

### Pacemakers

If you have a pacemaker:

- Always keep the Table pc more than 15 cm from your pacemaker when the Table pc is switched on, in order to avoid potential interference.
- Do not carry the Table pc in a breast pocket.
- Use the ear opposite to the pacemaker to minimize the potential interference.
- Switch off your Table pc if you suspect that interference is taking place.

### Hearing aids

If you are a user of a hearing aid, consult your physician and hearing aid manufacturer to learn whether your particular device is susceptible to cellular Table pc interference.

### How to prolong the battery life of your Table pc

To have your Table pc function properly, sufficient battery power is important. For the power-saving purpose, do the following, if applicable:

- Turn off the Bluetooth function of your Table pc.
- Set the backlight level and duration of your Table pc to a low value.
- Turn on the auto keypad lock, turn off the key sounds, tap vibration, or vibration alerts.
- Establish GPRS connection when needed. Otherwise, your Table pc will keep searching for GPRS connection, and drain your battery power.
- Turn off your Table pc if there is no coverage. Otherwise, the Table pc will keep searching for network, and drain your battery power.

## 6.Trouble shooting

Problem	Solution
The device will turn itself off after a few seconds	Check that the battery is charged.
No sound is heard	Adjust the volume level Check if audio file is broken
Screen is hard to see in bright light.	Adjust the screen brightness in the system menu. Avoid using the reader in direct sunlight.
Data on the screen is corrupted or a program is not responding properly	Check if the device is connected to the computer correctly. Check if the memory space is full. Check if the USB cable is broken

**Battery Model:** 2969100P-2500mAh 3.7V

LI-ION Battery Manufacturer

SHENZHEN UTILITY POWER SOURCE CO., LTD

ADD:Huiye Technology Park,Guanguang Road.

Guangming Distric,Shenzhen,China

### **Tablet Manufacturer**

China Greatwall Technology Group CO.,LTD

Add:Block A5, Greatwall Computer Industry Park,Baoshi East Rd.

Shiyan,Baoan,Shenzhen,China

\*Under optimal conditions ( i.e battery is fully charged and used at normal temperatures, LCD brightness at 50%, headset is us  
Android is a trademark of Google Inc.The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.

