

\*\*\* USER'S MANUAL \*\*\*

---

**FCC ID : P5AB71**

## **The Federal Communication Commission Statement**

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures: -


- **Reorient or relocate the receiving antenna.**
- **Increase the separation between the equipment and receiver.**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- **Consult the dealer or an experienced Radio/TV technician for help.**

Use only shielded cables to connect I/O devices to this equipment. You are cautioned that change or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: -

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

Congratulations on your purchase of the Rechargeable Cordless Optical Mouse, which includes the radio frequency and optical technologies for superior performance on your PC.



**Insert the batteries**

- Remove the battery compartment cover on the bottom of the mouse.
- Fit in the batteries according to the diagram indicated in the battery compartment.
- Close the battery compartment cover.

A wrong battery placement may cause a battery overheats.

**Note**

- For a supreme battery performance, it is **MUST** to fully charge the rechargeable batteries contained in this package at the first-time use. (Please refer to battery recharge instruction to charge the batteries.)
- The Cordless Optical Mouse unit offers a strong power saving management function. Once the mouse accesses the sleeping mode, to click any button of the mouse is compulsory to wake it up.


**Connect the receiver**

- Turn off your PC.
- Connect the receiver cable to PS2 or USB port on PC.
- Turn on your PC.



**Establish communication between the mouse and receiver**

- Press the ID search button on the receiver, and note the red LED will blink slowly.
- Press the ID change button on the bottom of the mouse to set a new ID. The red LED indicator will blink at a faster rate until an identical ID is located.



- The red LED indicator on the receiver will blink any time the mouse sends it a signal.

- Before installing the driver, we suggest you check if any other mouse driver is installed in your system. If yes, in order to avoid any conflicts, please un-install or remove that driver before installing the new driver.

- Insert the driver diskette into drive A or B, choose the "Start" menu, and select "Run". Type " ( drive ) : Setup" in the command line box, and select "OK". Then, follow the instructions on the screen, and RESTART the PC when the installation is completed.

**5. Customizing the mouse functions**

With the software provided, eight commonly-used tasks can be assigned to the programmable wheel button.

- Double click the "Wheel Mouse" icon at the lower right corner of Windows control panel.
- Select the "Programmable Button" to assign many frequently-used Windows and the Web functions as below: