

8 The usage of the "Set-up" function

- 1 step;

on the "Main" menu, push the "next/forward" button four times, it turns yellow on the character of "Setup", and then push the "Play/Pause" button



- 1) The usage of the "File" function
- 2) The usage of the "Option" function
- 3) The usage of the "System" function
- 4) The usage of the "Personal" function
- 5) The usage of the "Help" function



1) The usage of the "File" function

Delete Mode

- 1 step;

the screen will turn over like the right picture, then it is yellow on the character of "Delete", and then push the "Play/Pause" button



- 2 step;

the screen will turn over
"Delete" menu, and then
you can choose the file by
up/down button, if you
select the file, push
the "Next" button, and t
hen left side of content name will turn red checkmark on the screen



- 3 step;

the screen will turn over like
the right picture, and then
push the "Play/Pause" button
again, and then file
will be deleted.



Repeat mode

- Like the picture, the mode
will turn 3 kind modes by
pushing the "Play/Pause"
button one by one.
"ONE" : only one file
repeated
"ALL" : all contents list
repeated by orderly
"OFF" : just one time play,
not to repeat



Sorting mode

- Like the picture, the mode will turn 4 kind sub-modes by pushing the "Play/Pause" button



"Name-Korean"

"Name-English"

"Date"

"Size"

File list will be sorted by sub-mode.



Listing mode

- Like the picture, the mode will turn 3 kind sub-modes by pushing the "Play/Pause" button



"Internal"
file list of internal memory



"External"
file list of MMC/SD
Memory Card

"Both"
total list

File list will be displayed by sub-mode.

2) The usage of the "Option" function

- 1 step;

the screen will turn over like the right picture, then it is yellow on the character of "Option", and then push the "Play/Pause" button



- 2 step;

the screen will turn over like the right picture, then it is yellow on the character of "Auto-Naming Rule", and then push the "Play/Pause" button



- 3 step;

you can choose the two type of rules



Wallpaper

- 'off'
- 'on'

If you want, you choose the special wallpaper only for you.



3) The usage of the "System" function

- Main=> Setup and then choose the sub-mode of setup menu.



1 step;

the screen will turn over like the right picture, then it is yellow on the character of "System", and then push the "Play/Pause" button



- 2 step:
there are 5 kind of sub modes
Format/
Memory information/
Auto-off/
Factory default/
Backlight.



- [Format MODE]
Internal/ external memory
will be formatted.




- [Memory information MODE]
Storage capacity will be
displayed.




- [Auto-off MODE]
To save the power of
battery, it will be set
1MIN/2MIN/5MIN/10MIN/
off mode.



- [Factory default]
It will make all environment
of user's setting to
beginning time.



- [Backlight]
"0" ~ "3" : 4 different
degree can choose to
bright the screen.



4) The usage of the "Personal" function

- This function will help you to manage the device for identification.




- Please read carefully the "I-manager" software part.



5) The usage of the "Help" function

This function will be supported in the internet.



MEMO
