


NOTES:

1. ALL RESISTANCE VALUES ARE INDICATED IN "OHM" (K 1000 OHM)
2. ALL CAPACITANCE VALUES ARE INDICATED IN "uF"



SCHEMATIC DIAGRAM FOR BM101 BABY UNIT