




R39 & R40 FOR 5V
REGULATOR. R39 SHOULD BE
ZERO OHM & R40 NOT POPULATED.

+5V converter