







THUNDERTUMBLER®

**GENERAL CONTROLS** 

Spinning Action
Press and hold the control sticks

**Forward** 

Press both control

1) Spin the car by pressing and holding the control sticks in opposite directions.

REMOTE CONTROL ASSEMBLY

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

**Action Button** 

Press and hold the action button to have the car

2) Press and hold the action button while the car is spinning.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

1645854 (xxxxx)

94202 30906 Made in China

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undexical assertion.

RADIO CONTROL 360° RALLY CAR

**OPERATING INSTRUCTIONS -**

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

Locate the battery compartment on the back of each item (see diagram on right).
 Swivel latches on bottom of car to release battery pack

4 Switch both car and remote buttons to "ON" position. 5. For best result use the car on hard surfaces such as wood or tile.

1. Carefully remove items from package.

Press both control

SAFETY PRECAUTIONS

• Do not operate during thunderstorms or rain.

• Avoid water, sand and snow when operating car.

• Do not submerge car or controller in water.

Never operate your car on the street or highway.

damage to both the objects and the car.

animals as obstacles.

the car is switched to "ON".

long periods of time.

BATTERY WARNING:

Never operate your car in a confined or crowded area, and do not use people or

• Do not run your car into furniture, objects or hard surfaces, as this will cause

• Keep fingers, hair and loose clothing away from the tires, gears and motor while

Do not leave car or transmitter near sources of heat or under direct sunlight fo

• Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.

Remove all batteries when not in use to avoid accidental operation.

Adult supervision is recommended when operating this car.

and insert batteries.

