13 x 5.25 x 7 in

VERSATILE
DRIFT-STYLE RACING ACTION ON SMOOTH SURFACES

FULL FUNCTION
REMOTE TO PERFORM AMAZING TRICKS
FULL FUNCTION MULTI-DIRECTION

WIRELESS
REMOTE CONTROL FOR FULLY FUNCTIONAL RACING ACTION

DRIFT STYLE RACER

MULTI-DIRECTIONAL OPERATION

THE BLACK SERIES™ by shift3®

radio controlled action vehicle

nitro drift car

THE BLACK SERIES™

by shift3®

JL2014D
Toy RC Drifter

BOX CONTAINS THE FOLLOWING FREQUENCY:
- ☐ 27 MHz
- ☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE
AGES 6 AND UP

⚠ WARNING!
CHOKING HAZARD -
Small parts. Not suitable for children under 3 years.

DRIFT STYLE RACER

STREET RACING STUNT CAR

FULL FUNCTION REMOTE CONTROL

radio controlled action vehicle

nitro drift car

drift-style racing action on smooth surfaces

radio controlled action vehicle

nitro drift car

BATTERY INSTALLATION

The car requires 4 "AA" 1.5V batteries (not included). The controller requires one 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for the best performance.

- Carefully remove items from the package.
- Locate the battery door on the bottom of the car. Using a Phillips screwdriver, remove the screw.
- Pull the latch on the door to the left and lift up to access the battery compartment. Insert 4 "AA" batteries while observing the correct polarity. (Fig.1)
- Replace the battery compartment door.
- Repeat process on the back of the remote control to open battery door.
- Insert one 9V battery while observing the correct polarity (Fig.2).
- Replace the battery compartment door.
- Switch both the car and controller power switches to the "ON" position.

NOTE: For best operation, operate car on a hard surface.

Fig.1



Fig.2



SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating vehicle.
- Do not submerge vehicle or controller in water.
- Never operate vehicle on the street or highway.
- Adult supervision is recommended when operating vehicle.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the vehicle is switched to "ON".
- Do not leave vehicle or controller near sources of heat or under direct sunlight for extended periods.
- Do not leave vehicle or controller outside overnight. Dampness is harmful to interior components.

REMOTE CONTROL UNIT (USES ONE "9V" BATTERY (NOT INCLUDED))

BATTERY WARNING

Battery Information

- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Batteries should be replaced by an adult.
- Nonrechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under the adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not dispose of batteries in fire.

KEEP THIS INSTRUCTION SHEET FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

This toy complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the equipment with respect to the receiver.
- Move the equipment away from the receiver.
- Plug the equipment into a different outlet so that equipment and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/TV technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

©2014 MotorSource, LLC. Shift3, The Black Series, The Black Series 3in [SHIFT], and all associated logos are trademarks of MotorSource, LLC. All rights reserved. Distributed by MotorSource, LLC, Irvine, CA 92618.
US Patent No. 7,281,918; 8,152,610; 7,934,962
The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. The trademarks and trade names of others used in this material are the property of their respective owners. For more information, visit www.shift3.com or call 1-800-374-7744.

29030328 (33459)

Made in China