

**CAUTIONS AND INSTRUCTION****FOR Model BU5-25W BU4-20/14W BH4-11X FB52-14**

1. Never drop or strike the lamp.
2. The lamp should not be disassembled or modified.
3. Never hold the glass tube by hand when installing.
4. Use only on 120Vac,60Hz. Never use with a direct current, Otherwise the lamp will stop working.
5. Use indoors at a room temperature ranging from 41°F(5°C) to 95°F(35°C).
6. Never use where water may drop on the lamp .
7. Never use in front of or over a room heater ,make sure that the lamp is firmly screwed into the socket. Otherwise, the lamp may drop or result in an electric disconnection.
8. When the lamp is switched on ,dark spots may be observed around the tube-end. This is normal . To prevent risk of a burn, never touch the lamp with bare hands or face while in operation.
9. Contains traces of mercury, Avoid throwing out spent bulbs in the household trash. To reduce the risk of bulb breakage and contamination, wrap the bulb in a sealed plastic bag. Never incinerate bulbs. Check for local disposal or recycling programs that accept spent bulbs. A short circuit fuse is built into this lamp. If it is damaged do not attempt to disassemble or repair the lamp. Added weight may cause instability of free-standing portable lamps. Use only with portable lamps in which the distance from the bottom of the base to the top of the lamp holder does not exceed three (3) times minimum base width. This device is not intended for use with emergency exit fixtures or emergency lights.
10. Added weight of the device may cause instability of a free-standing portable lamp. Use only with portable table lamps in which the distance from the bottom of the base to the top of the lampholder does not exceed three(3) times minimum base width. Use only with portable table lamps which are provided with lamp shades.
11. Use Only in dry location.
12. Not for use where exposed to the weather(Ne pas faire fonctionner dans un emplacement exposé aux intempéries).
13. Not for use in luminaires controlled by a dimmer(Ne pas relier à un luminaire commandé par un gradateur).
14. Not for use in totally enclosed recessed luminaires(Ne pas installer dans des luminaires encastrés non ventilés).

**Label:****CAUTION:**

**RISK OF ELECTRIC SHOCK**—Use only in dry location.

Not for use in luminaries controlled by a dimmer

(Ne pas relier a un luminaire commande par aux grandateur).

Not for use in totally enclosed recessed luminaries

**This Product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.15-30 MHz.**

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT