



Section 6


Test Setup Photographs




General Test Bench Setup




Transmit Harmonics Test Setup



Radiation Hazard Test Setup




Setting Laser Level For 20 cm



Taking Reading Using Laser Level To Indicate 20 cm Point



Frequency Stability Test Setup



Frequency Stability Test Setup (Inside Chamber)