



H6958-0920  
H6958-9993-S1

## TYCO® R/C SUPPORT

Questions or problems with your product?  
**DON'T RETURN IT TO THE STORE!**  
Just call us for help.

U.S. consumers may also register their products at this number.

**1 888 557-TYCO (8926)**

**tycorc.com**

# 6.0V R/C

Keep these instructions for future reference: they contain important information. **IMPORTANT: Please read all "Consumer Information" before operating your vehicle.**

**⚠ CAUTION:** Surfaces may become hot and cause burns if electronics get wet. Do not operate vehicle through water or snow.

## I. CONTENTS/FEATURES



### Vehicle

- ❶ Steering Adjuster
- ❷ Battery Door
- ❸ 3 AA Try-me Batteries
- ❹ ON/OFF/Try-Me switch

☀ This switch has three positions:





- ❶ Vehicle On: Vehicle runs with lights as you drive
- ❷ Vehicle OFF
- ☀ Vehicle On: Activates 'try me' function with lights

- ❸ Lights
- ❹ Try-Me button-with lights




### Transmitter

- ❶ Antenna
- ❷ Vehicle Controls
- ❸ Battery Door




## II.VEHICLE OPERATION


### FORWARD




### REVERSE



### LEFT



### RIGHT



## III.BATTERY INSTALLATION


Requires 6 AA Alkaline Batteries (2AA for transmitter and 4 AA for vehicle). Batteries included are for demonstration purposes only.

### Vehicle

1. Use a screwdriver (not included) to unscrew the power clip cover screw, open the battery cover as shown.
2. Remove 3 "AA" batteries (included for Try-Me Lights ONLY) and replace with 4 new "AA" alkaline batteries (not included) with polarity (+/-) as shown inside the battery compartment.
3. Replace the battery door.

### Transmitter

1. Remove the battery cover as shown.
2. Install 2 AA alkaline batteries(not included) with polarity (+/-) as shown inside the battery compartment.
3. Replace the battery door.


 Your transmitter is equipped with a special automatic ON battery-saving feature. Just turn your vehicle ON. Then push either transmitter control to run and control your vehicle.

## IV.CONSUMER INFORMATION

Note to Adults: To ensure that the child's play is both safe and fun, please review all operating instructions and safety rules with your child.

### Safety Tips

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion.
- Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is switched ON.



 **CAUTION:** To prevent entanglement, keep hair away from wheels.

- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries when not in use. Always turn the vehicle OFF before removing batteries.

### BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).





- Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery (ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

### Battery Performance Note:

For best performance use regular or high-performance alkaline batteries (where disposable batteries are called for). If your vehicle is supplied with standard (carbon-zinc) batteries for initial use and/or demonstration purposes, we recommend replacing them with alkaline batteries when necessary. Battery life may vary depending on battery brand.

## V. QUICK TIPS

1. When your vehicle starts to lose power, it may lose functions or performance. It's time for fresh batteries (or a recharge). Your vehicle's running time may change depending on your driving style.
2. Radio interference can make your vehicle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires; large buildings; or CB radios. Try to stay away from these!
3. Point your transmitter antenna up - not down toward your vehicle. If your vehicle gets too far away, it won't work properly. If your transmitter has an antenna carry-loop feature, make sure the antenna is removed from the holder and straightened before operating.
4. Don't drive your vehicle in sand or through water or snow.
5. Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.



## TROUBLESHOOTING - PROBLEM? - SOLUTIONS

### SYMPTOM

### • PROBABLE CAUSE

### • CORRECTION

Vehicle runs slowly or will not run.

- Loose battery connection or vehicle switch not ON.
- Weak or uncharged rechargeable NiCd battery.
- Weak AA batteries (Power Clip) or transmitter battery.

- Check battery connector and vehicle switch.
- Charge battery or replace.
- Replace with fresh alkaline battery.

Power indicator light on transmitter does not light.

- Transmitter battery weak or not connected.

- Check connections and replace battery if required.

Erratic operation or only short range possible.

- Radio interference likely.

- Change location - see Point 2, "Quick Tips."

Vehicle doesn't work after going through water or snow.

- Water in the electronics area.

- Vehicle will take several hours to dry. Allow to dry thoroughly overnight before trying again.
- Avoid driving in water or snow.

## 90-DAY LIMITED WARRANTY – TYCO® R/C PRODUCTS

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material and workmanship for ninety (90) days (unless specified in alternate warranties) from the date of purchase. Mattel will replace the product in the event of such a defect within the warranty period.

In the event of a defect covered under this warranty, first call the toll-free number listed below. Many problems can be solved in this manner. If necessary, you will be instructed to return the product, postage prepaid and insured, to the address below. Enclose your name, address, dated sales receipt, and a brief explanation of the defect. Replacement and return shipment will be free of charge.

This warranty does not cover damage resulting from unauthorized modification, accident, misuse or abuse. If the product is returned without a dated sales receipt the product may be excluded from coverage under this warranty.

Mattel's liability for defects in material and workmanship under this warranty shall be limited to replacement, and in no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). This warranty is exclusive, and is made in lieu of any express or implied warranty. **Valid only in U.S.A.** This warranty gives you specific legal rights and you may have other rights, which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

TOLL-FREE NUMBER: 1-888-557-TYCO (8926) (**valid only in U.S.A.**) Hours: 8:00 A.M. - 5:00 P.M. Eastern Time; Monday - Friday. Expect some delay in January following the holiday season. Please be patient and keep trying the toll-free number. ADDRESS FOR RETURNS: CONSUMER RELATIONS, 636 GIRARD AVENUE, EAST AURORA, NY 14052

© 2005 Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245  
U.S.A. Consumer Affairs: 1 (800) 524-TOYS. **PRINTED IN CHINA.**  
All Rights Reserved. MATTEL, TYCO and associated trademarks  
and trade dress are owned by Mattel, Inc. Retain this address  
for future reference: Mattel U.K. Ltd., Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia  
Pty Ltd., Richmond, Victoria 3121 - Consumer Advisory Service:  
1300 135 312. Mattel East Asia Ltd, Room 1106, South Tower,  
World Finance Centre, Harbour City, Tsimshatsui, HK, China.  
Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot  
47410 P.J. Tel: 03-78803817,  
Fax: 03-78803867.

#### **COMPLIANCE WITH FCC REGULATIONS (VALID IN U.S. ONLY)**

This device complies with part 15 of the FCC Rules.  
Operation is subject to the following two conditions: (1)  
This device may not cause harmful interference, and (2)  
this device must accept any interference received,  
including interference that may cause undesired operation.  
This device generates and uses radio frequency energy  
and if not used properly may cause interference to radio  
and television reception. It has been tested and found to  
comply with the limits set by the FCC which are  
designed to provide reasonable protection against such  
interference.

**NOTE:** Changes or modifications not expressly  
approved by the manufacturer responsible for compli-  
ance could void the user's authority to operate the  
equipment.