

Conducted Test Setup Placement: (Charging mode)



Front View of the Test Configuration



Rear View of the Test Configuration

Conducted Test Setup Placement: (Operating mode)



Front View of the Test Configuration



Rear View of the Test Configuration

Radiated Test Setup Placement: (BASE)



Front View of the Test Configuration of X-axis of Base




Front View of the Test Configuration of X-axis of Base

Radiated Test Setup Placement: (Handset)



Front View of the Test Configuration of X-axis



Front View of the Test Configuration of Y-axis