

Conducted Test Setup Placement: (Charging mode)



Front View of the Test Configuration



Side View of the Test Configuration

Conducted Test Setup Placement: (Operating mode)



Front View of the Test Configuration




Side View of the Test Configuration

Radiated Test Setup Placement: (BASE)



Front View of the Test Configuration of X-axis



Rear View of the Test Configuration of X-axis

Radiated Test Setup Placement: (Handset)



Front View of the Test Configuration of X-axis



Rear View of the Test Configuration of X-axis