

DSRC Reader V2- FCC 15.19 Label Placement
Place Label on left side of housing as shown.

