



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

- Pb = Battery contains lead
- Cd = Battery contains cadmium
- Hg = Battery contains mercury

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :
 1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
 - Consult the dealer or an experienced radio/TV technician for help.

Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty:

All Maisto R/C products have a 30 days limited warranty in function and performance. You may receive a new replacement product if the defective product is returned to Maisto freight prepaid and confirmed a factory defective. Maisto's 30 days warranty is limited to factory defects in material and workmanship only. The warranty does not cover unauthorized modification, accidents, abusive use, and consequential damages per our judgment. The warranty is limited to original purchaser with dated proof of purchase only. If you have problem with our product, e-mail or call customer service first. RA # may be issued if problem cannot resolved over the phone or email. Return for repair or replacement must be shipped prepaid/postage prepaid and insured, include dated proof of purchase, RA# and brief description of problem. If product is returned without a dated proof of purchase, it will be excluded from the coverage of this warranty. Allow 3 to 5 weeks for delivery of repaired or replacement per Maisto's discretion. Delivery is limited in U.S.A. or Canada only. Warranty is only valid for purchases in U.S.A and Canada only. Check the FAQ section before you return the product to Maisto.

FAQ (Frequently Asked Questions)

1) Why does my Project: 66™ not start?

Make sure that the car and transmitter are set to the same channel (A, B or C).
 Make sure the transmitter and the vehicle are turned on.
 Check to make sure the batteries are not drained.
 Make sure the batteries are installed per polarity indicators.
 Make sure all 4 wheels are not obstructed by any foreign objects.

2) Why does my Project: 66™ make unusual noises?

Check to make sure the batteries are not drained.
 Check to make sure all 4 wheels are not obstructed by any foreign objects.
 Check to make sure no foreign object is inside the vehicle.

3) Why the missile can not be inserted into the launcher?

Check to make sure the missiles are not being deformed and damaged.
 Check to make sure the launcher is not obstructed by any foreign objects.
 Check to make sure the missiles are supplied or recommended by the manufacturer.
 Slightly adjusting the launcher by pressing the shoot button should help to install the missile.

4) What if I'm still having a problem?

Check the FAQ and make sure all attempts have been made to make the unit work.
 Check your purchase receipt date and make sure it's within the 30 days warranty period at the time you intend to send it back.
 Contact Maisto (see below), and tell us the model that you have, the problem(s) you are having, your daytime phone number, and any other information that might be helpful to us to correct the problem.
 If Maisto cannot solve your problem by mail, email or telephone, we will issue a return authorization number so you can return the unit to us for repair or replacement. **No returns will be accepted without a return authorization (RA) number issued by Maisto clearly marked on the outside of the package.** Pack the unit back in its original box or another box with sufficient protective material, include a copy of your dated store receipt and a description of the problem then send it freight prepaid to the address which we will provide once you receive your RA number.

5) Please refer to FAQ section in our website for more information.

Website: www.maisto.com
 Email: customerservice@MayCheongGroup.com
 Phone: (909) 357-7988
 8:30 a.m. - 5:00 p.m. / Monday-Friday / Pacific Time
 Maisto International, Inc., Fontana, CA 92336, U.S.A.



www.maisto.com
MADE IN CHINA Eng (R5)



WARNING:
CHOKING HAZARD - Small parts.
 Not for children under 3 years.



Warning! Do not aim at eyes or face

Warning! Do not use projectiles other than those supplied or recommended by the manufacturer.

To prevent pinch happens, do not grasp the vehicle by hand or other part of human body while vehicle in running or transformation.

Do not operate the remote controller while you are holding the vehicle.

Maisto Radio Control Vehicles

Please keep this owner's instruction manual for future reference. It contains important information. We reserve the right to improve/revise the product specifications without notice. Class 1 LED Product

Contents:

- Vehicle x 1
- Transmitter x 1
- Missile x 8 (5 + 3 spares)
- Owner's Instruction Manual x 1


Battery Requirement:

Vehicle: 6 X 1.5V "AA" LR6 batteries
 Transmitter: 2 X 1.5 "AA" LR6/R6 batteries

Battery installation for the Transmitter: (Refer to Diagram 1)

1. Switch the transmitter power OFF.
2. Open the battery cover.
3. Install 2 new 1.5V "AA" LR6/R6 batteries following the polarity (+/-) marked inside the battery compartment.
4. Install the battery cover.

Diagram 1 Battery installation




Size: A4_210mm(W) x 297mm(H)
 Color: 1C (Black)

MAY CHEONG TOY PRODUCTS FTY. LTD.			DIECUT
Job Item: N-Art140/09 R1	Finished by: LOUIS	Date: 07-08-2012	Test No.:
Item No.: #81107 Eng	Check by:	Date:	File Name:

Battery Installation for the Vehicle (Refer to Diagram 2)

1. Switch the power OFF.
2. Use screwdriver to loosen the screw on the battery cover and to open the battery cover. (Screwdriver is not included).
3. Take the battery holder out and install 6 new 1.5V "AA" LR6 batteries following the polarity (+/-) marked inside the battery compartment.
4. Insert the battery holder back then install the battery cover and tighten the screw on the battery cover.
5. Should difficulty arise in opening (or closing) the battery cover, press the fender closer to (or away from) vehicle to improve the connection points.

Diagram 2 Battery installation





How to play: (Refer to Diagram 2 & 3)

1. Match the transmitter with the Vehicle Channel (Channel A to A, B to B or C to C).
2. Switch the transmitter ON, the Transformation button lights up.
3. Switch the Vehicle ON.
4. Follow A, B and C below to transform the vehicle, shoot missiles and drive.
5. Switch OFF the transmitter and the vehicle after playing.

A) Transformation (Refer to Diagram 4)

- Press the transformation button and transform into different modes.
- Please note : when the body is opened in fire mode, and the red button is continually pressed, a ratchet sound may be heard. This is a preventative function, and no harm to your vehicle is being done.


Diagram 3



B) Missile Launch (Refer to Diagram 5 & 6)

- Transform into attack mode and Insert 5 missiles (Missile size: Length: 84.5mm ; Diameter: 4.5mm) into the launcher.
- Press the shoot button to shoot missiles. (Range of Fire : 2m)
- Do not aim or shoot missiles at persons or animals.
- When inserting missiles, do not directly face the firing mechanism, and never have your face directly in front of the firing mechanism.


Diagram 5



C) Movement (Refer to Diagram 7)

- Push the left / right levers up or down to move the vehicle.

Diagram 7



Performance Tips:

1. Do not drive the vehicle on grass, sand or go through water.
2. Do not use projectiles other than those supplied or recommended by the manufacturer.
3. Do not drive the vehicle into any hard object.
4. Always switch the power to OFF on the transmitter and vehicle when you are done playing.
5. Keep fingers, hair and loose clothing away from the vehicle.
6. The operating range can be affected by a variety of factors:
 - a) Weak transmitter or vehicle batteries.
 - b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
7. Make sure all missiles are securely inserted into the launcher.
8. Remove any foreign object inside the vehicle before transformation each time.
9. Missiles can only be fired after the vehicle has fully transformed into attack mode.
10. Outdoor usage is recommended in order to get optimal control range (32 feet or 10 meters).

NOVICE TIP
 Try loading only 4 darts at a time for easy loading!

Cautions:

1. Do not aim missiles at face or eyes at any time.
2. Do not use projectiles other than those supplied or recommended by the manufacturer.
3. Do not pick up the vehicle while it is in motion.
4. Do not pick up the vehicle by holding the wind shield or the rear wing.
5. Do not hold the wheels while the vehicle is moving.
6. Do not bend the wind shield, body and missiles of the vehicle.
7. Keep fingers, hair and loose clothing away from the wheels.
8. Do not try to transform when there is something obstructing the vehicle.
9. Shoot missiles only when the vehicle is fully transformed into attack mode.
10. Do not use force to pull missiles out from launcher.
11. Missiles must be removed when the vehicle is not in use.

PRO TIP
 When you become a master with your controller, gently tap the fire button to load fifth dart!

Battery use:

1. Alkaline batteries are recommended.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Do not mix alkaline, standard or rechargeable batteries.
4. Do not mix old and new batteries or different type of batteries.
5. Non-rechargeable batteries are not to be charged.
6. If rechargeable batteries are to be used, they are only to be charged by adult.
7. Rechargeable batteries are to be removed from the product before they are charged.
8. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
9. Remove all batteries from the product when not in use for long periods of time.
10. Exhausted batteries are to be removed from the product.
11. The supply terminals are not to be short-circuited.
12. Dispose of batteries properly. Do not dispose of batteries in fire - it may cause them to explode or leak causing injury or damage.
13. Battery change must only be made by adult.

Disposal of batteries:

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.