

FCC ID: PKHMRCHRISTMAS

Operation Description:

There are two buttons on the EUT, The button on the left hand control the rotating movement of the car. The button on the right control the forward movement of the car.

The brief circuit description is listed as follows:

- Q1, Q6 and associated circuit act as signal generator.
- C5 and associated circuit act as local oscillator.

Antenna Used:


A permanent wire antenna has been used.

INSTRUCTION MANUAL

SERVING SANTA

TO OPERATE:

1. Place the figure on the floor.
2. Turn the power switch (which is located at the side of the round base of the figure) to the " ON " position.
3. Push the **TURNING BUTTON** of the remote control (SEE FIG. I) to turn the figure facing any direction as desire. Release the **TURNING BUTTON** to stop the figure turning. Then push the **FORWARD BUTTON** (SEE FIG. I), the figure will move toward the choosen direction. Release the **FORWARD BUTTON** to stop the figure moving.
4. Turn the power switch to the " OFF " position when no in use.



WARNING : CHANGES OR MODIFICATION TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

hys12000