

## Ultra Score Control Test Procedure

- 1) Install batteries in the control to be tested.
- 2) Power on the test unit.
- 3) Press the "HORN" key, a "0" should be displayed on the test unit.
- 4) Press "HOME" then "+", a "1" should be displayed on the test unit.
- 5) Press "GUEST" then "-", a "2" should be displayed on the test unit.
- 6) Press "MINUTE" then "+", a "3" should be displayed on the test unit.
- 7) Press "SECOND" then "-", a "4" should be displayed on the test unit.
- 8) Press "PERIOD" then "+", a "5" should be displayed on the test unit.
- 9) Press the "Clear" key, a "6" should be displayed on the test unit.
- 10) Press the "Function" key, a "7" should be displayed on the test unit.
- 11) Press the "RUN" key, a "8" should be displayed on the test unit.
- 12) Press the "STOP" key, a "9" should be displayed on the test unit.

If all numbers are successfully displayed, the control has passed testing.

If any number fails to display, the control has failed testing.