



5.2 Function Window

Function Window shows the each function of the DJPAD2020 S/W (Play List, Scratch pad, Effect Pad, Drum Loop, EQ/Reverb, Mixer). So this window changes every time when user choose the function in the control window. But each function works with the function of the virtual turntable window. So many variable parameters are displayed in each function window you choose. The detailed functions in this window will be explained in the following chapter 6. Function of DJPAD2020.



(Fig. 9) Function Window - Play List, Scratch Pad, Effect Pad, Drum Loop, Sampler, Mixer

5.3 Control Window

Control window can make selection of each function part (Play List, Scratch Pad, Effect pad, Drum loop, Sampler and Mixer) and each function window shows up after you choose and click the function button. Each function part works independently or work together with the functions of virtual turntable window. Also using "Tab" key in your keyboard, you can change function window as in order of Play List, Scratch, Effect, Drum Loop, EQ/Reverb, Mixer.



(Fig. 10) Control Window