


AXIS M1065-LW, AXIS M1045-LW,
and
AXIS Companion Cube LW

FCCID: PNB-AXISM1065-LW

Label drawing

Label location



Labels used on AXIS M1065-LW:

Label 1

FCC ID: PNB-AXISM1065-LW R12 CAN ICES-3 (B)/NMB-3(B) FCC, see manual IC:3919A-M1065LW Axis Communications AB, Emdalav. 14, SE-22369 Lund, SWEDEN	
Micro USB Type B 1A 65807r1	 AXIS M1065-LW S/N: ACCC8E2EFCCE P/N: 0810-004-01 Engineered in Sweden Country Of Origin: CZECH REPUBLIC

Label 3

Label 4

Label 2



Labels used on M1045-LW:

Label 1

FCC ID: PNB-AXISM1065-LW R12 CAN ICES-3 (B)/NMB-3(B) FCC, see manual IC:3919A-M1065LW Axis Communications AB, Emdalav. 14, SE-22369 Lund, SWEDEN	
Micro USB Type B 1A 65807r1  AXIS M1045-LW S/N: ACCC8E2EFCCE P/N: 0812-004-01 Engineered in Sweden Country Of Origin: CZECH REPUBLIC	

Label 3

Label 4

Label 2



Labels used on AXIS Companion Cube LW:

Label 1

FCC ID: PNB-AXISM1065-LW R12 CAN ICES-3 (B)/NMB-3(B) FCC, see manual IC:3919A-M1065LW Axis Communications AB, Emdalav. 14, SE-22369 Lund, SWEDEN	
Micro USB Type B 1A 65807r1  AXIS COMPANION CUBE LW S/N: ACCC8E2EFCCE P/N: 0892-004-01 Engineered in Sweden Country Of Origin: CZECH REPUBLIC	

Label 3

Label 4

Label 2

