

Re: Auto Scan function explanation

On the channel selector of receiver, when more than one channel is selected, the auto scan function is on; Otherwise, when only one channel is selected, the auto scan function is off.

When auto scan function is on, the receiver is always receiving; and changing the receiving frequency within these selected channels automatically per 5 seconds.

Erin Chu

Product Engineer

ELANsat Technologies Inc.

9- Chullos'or