


14. ANTENNA LOCATIONS AND SEPARATION DISTANCES

14.1. ANTENNA-TO-USERS AND NEARBY PERSONS


Lap-held configuration

(Separation distance between antenna and user)




Nearby person configuration

(Separation distance between antenna and nearby person)



14.2. ANTENNA-TO-ANTENNA



15. TEST SETUP PHOTOS

Lap-held w/ 0.0 cm from the bottom of the laptop base-to-phantom
(1.1 cm distance from Main/Aux antenna-to-phantom)



16. HOST DEVICE PHOTO



END OF REPORT