





# LATITUDE XX

## Setup and Features Information

### Views | Views | Views | Views | Views



Stylus (optional) | Stylus (optional) | Stylus (optional) | Stylus (optional) | Stylus (optional)



- 1 cooling vents
- 2 microphone
- 3 camera LED
- 4 front camera
- 5 microphone
- 6 cooling vents
- 7 touch screen
- 8 microphone
- 9 power LED
- 10 power button
- 11 speaker
- 12 microphone
- 13 Noble security lock slot
- 14 memory card reader
- 15 micro USB/power connector
- 16 mini HDMI connector
- 17 start button
- 18 security card reader
- 19 finger print reader
- 20 rear camera
- 21 docking guide slot
- 22 dock pins
- 23 keyboard connector
- 24 dock pins
- 25 docking guide slot
- 26 USB 3.0 connector
- 27 speaker
- 28 volume decrease button
- 29 volume increase button
- 30 audio connector
- 31 Ambient Light Sensor
- 32 Pen Tip (replaceable)
- 33 Programmable button
- 34 Programmable button

Language | Language | Language | Language

- 1 Language
- 2 Language
- 3 Language
- 4 Language
- 5 Language
- 6 Language
- 7 Language
- 8 Language
- 9 Language
- 10 Language
- 11 Language
- 12 Language
- 13 Language
- 14 Language
- 15 Language
- 16 Language
- 17 Language
- 18 Language
- 19 Language
- 20 Language
- 21 Language
- 22 Language
- 23 Language
- 24 Language
- 25 Language
- 26 Language
- 27 Language
- 28 Language
- 29 Language
- 30 Language
- 31 Language
- 32 Language
- 33 Language
- 34 Language

### Specifications

**NOTE:** Offerings may vary by region. The following specifications are only those required by law to ship with your tablet. For more information regarding the configuration of your tablet, go to **Start Screen** → **Help and Support** and select the option to view information about your tablet.

Power	
Coin-cell battery	3 V CR2025 lithium ion
Input voltage	100 VAC - 240 VAC
Output Power	19.5V, 1.2A
Physical	
Height	12.2mm (0.48 inch)
Width	279.74mm (11.01 inches)
Depth	176.76mm (6.96 inches)
Weight (Minimum)	870grams (1.91 lbs)
Environmental	
Operating Temperature	0 °C to 35 °C (32 °F to 95 °F)

### Language

**LANGUAGE:** Offerings may vary by region. The following specifications are only those required by law to ship with your tablet. For more information regarding the configuration of your tablet, go to **Start Screen** → **Help and Support** and select the option to view information about your tablet.

Power	
Coin-cell battery	3 V CR2025 lithium ion
Input voltage	100 VAC - 240 VAC
Output Power	19.5V, 1.2A
Physical	
Height	12.2mm (0.48 inch)
Width	279.74mm (11.01 inches)
Depth	176.76mm (6.96 inches)
Weight (Minimum)	870grams (1.91 lbs)
Environmental	
Operating Temperature	0 °C to 35 °C (32 °F to 95 °F)

### Language

**LANGUAGE:** Offerings may vary by region. The following specifications are only those required by law to ship with your tablet. For more information regarding the configuration of your tablet, go to **Start Screen** → **Help and Support** and select the option to view information about your tablet.

Power	
Coin-cell battery	3 V CR2025 lithium ion
Input voltage	100 VAC - 240 VAC
Output Power	19.5V, 1.2A
Physical	
Height	12.2mm (0.48 inch)
Width	279.74mm (11.01 inches)
Depth	176.76mm (6.96 inches)
Weight (Minimum)	870grams (1.91 lbs)
Environmental	
Operating Temperature	0 °C to 35 °C (32 °F to 95 °F)

### Language

**LANGUAGE:** Offerings may vary by region. The following specifications are only those required by law to ship with your tablet. For more information regarding the configuration of your tablet, go to **Start Screen** → **Help and Support** and select the option to view information about your tablet.

Power	
Coin-cell battery	3 V CR2025 lithium ion
Input voltage	100 VAC - 240 VAC
Output Power	19.5V, 1.2A
Physical	
Height	12.2mm (0.48 inch)
Width	279.74mm (11.01 inches)
Depth	176.76mm (6.96 inches)
Weight (Minimum)	870grams (1.91 lbs)
Environmental	
Operating Temperature	0 °C to 35 °C (32 °F to 95 °F)



Bateria integrada de ion de lítio recarregável:

Marca: Dell Modelo: FWRM8 (7.4Vdc, 30Wh)/ PPNPH (7.4Vdc, 60Wh).

Carregador: PA-1300-04.

Este produto está homologado pela Anatel, de acordo com os procedimentos regulamentados pela Resolução nº 242/2000 e atende aos requisitos técnicos aplicados, incluindo os limites de exposição da Taxa de Absorção Específica referente a campos elétricos, magnéticos e eletromagnéticos de radiofrequência, de acordo com as Resoluções nº 303/2002 e 533/2009. Este dispositivo está em conformidade com as diretrizes de exposição à radiofrequência quando posicionado a pelo menos 1,0 centímetro de distância do corpo. Para maiores informações, consulte o site da ANATEL - [www.anatel.gov.br](http://www.anatel.gov.br)



**NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.


**NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.

**NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.

**NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.

**NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.

1



Connect the AC adapter to the AC adapter connector on the tablet and to the electrical outlet.

Connect the AC adapter to the AC adapter connector on the tablet and to the electrical outlet.

Connect the AC adapter to the AC adapter connector on the tablet and to the electrical outlet.

Connect the AC adapter to the AC adapter connector on the tablet and to the electrical outlet.

Connect the AC adapter to the AC adapter connector on the tablet and to the electrical outlet.

2



Press the power button to turn on the tablet.

Press the power button to turn on the tablet.

Press the power button to turn on the tablet.

Press the power button to turn on the tablet.

Press the power button to turn on the tablet.



### Start screen

You can get to the Start screen by swiping in from the right edge of your screen and tapping the **Start charm**.

Or point the mouse at the lower or upper right corner of the screen and then click the **Start charm**.

### Close App

If you're using a mouse, click the top of the app and drag it to the bottom of the screen. If you're using touch, drag the app to the bottom of the screen.

**NOTE:** When you're not using an app, Windows will remain open in the background and it will close eventually.



### Shutdown

- Swipe in from the right edge of the screen, and then tap Settings. If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Settings**.
- Tap or click **Power**, and then tap or click **Shut down**.

### Language

You can get to the Start screen by swiping in from the right edge of your screen and tapping the **Start charm**.

Or point the mouse at the lower or upper right corner of the screen and then click the **Start charm**.

### Language

If you're using a mouse, click the top of the app and drag it to the bottom of the screen. If you're using touch, drag the app to the bottom of the screen.

**NOTE:** When you're not using an app, Windows will remain open in the background and it will close eventually.

### Language

- Swipe in from the right edge of the screen, and then tap Settings. If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Settings**.
- Tap or click **Power**, and then tap or click **Shut down**.

### Language

You can get to the Start screen by swiping in from the right edge of your screen and tapping the **Start charm**.

Or point the mouse at the lower or upper right corner of the screen and then click the **Start charm**.

### Language

If you're using a mouse, click the top of the app and drag it to the bottom of the screen. If you're using touch, drag the app to the bottom of the screen.

**NOTE:** When you're not using an app, Windows will remain open in the background and it will close eventually.

### Language

- Swipe in from the right edge of the screen, and then tap Settings. If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Settings**.
- Tap or click **Power**, and then tap or click **Shut down**.

### Language

You can get to the Start screen by swiping in from the right edge of your screen and tapping the **Start charm**.

Or point the mouse at the lower or upper right corner of the screen and then click the **Start charm**.

### Language

If you're using a mouse, click the top of the app and drag it to the bottom of the screen. If you're using touch, drag the app to the bottom of the screen.

**NOTE:** When you're not using an app, Windows will remain open in the background and it will close eventually.

### Language

- Swipe in from the right edge of the screen, and then tap Settings. If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Settings**.
- Tap or click **Power**, and then tap or click **Shut down**.

### Language

You can get to the Start screen by swiping in from the right edge of your screen and tapping the **Start charm**.

Or point the mouse at the lower or upper right corner of the screen and then click the **Start charm**.

### Language

If you're using a mouse, click the top of the app and drag it to the bottom of the screen. If you're using touch, drag the app to the bottom of the screen.

**NOTE:** When you're not using an app, Windows will remain open in the background and it will close eventually.

### Language

- Swipe in from the right edge of the screen, and then tap Settings. If you're using a mouse, point to the upper-right corner of the screen, move the mouse pointer down, and then click **Settings**.
- Tap or click **Power**, and then tap or click **Shut down**.

## Information para NOM (únicamente para México)

The following information provided on the device described in this document in compliance with the requirements of the official Mexican standards (NOM)

Voltaje de alimentación	100 V AC - 240 V AC
Frecuencia	50 - 60 Hz
Consumo eléctrico	0,6 A
Voltaje de salida	5 V de CC ~ 19,5 V de CC
Intensidad de salida	2 A ~ 1,2 A

## More Information

For regulatory and safety best practices see the safety and regulatory documents that shipped with your tablet and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

See [www.dell.com](http://www.dell.com) for additional information.

## More Information

For regulatory and safety best practices see the safety and regulatory documents that shipped with your tablet and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

See [www.dell.com](http://www.dell.com) for additional information.

## More Information

For regulatory and safety best practices see the safety and regulatory documents that shipped with your tablet and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

See [www.dell.com](http://www.dell.com) for additional information.

## More Information

For regulatory and safety best practices see the safety and regulatory documents that shipped with your tablet and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

See [www.dell.com](http://www.dell.com) for additional information.

## More Information

For regulatory and safety best practices see the safety and regulatory documents that shipped with your tablet and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

See [www.dell.com](http://www.dell.com) for additional information.

Regulatory Model Language Language Language Language	T07G
Regulatory Type Language Language Language Language	T07G001