

INSPIRON 14


Quick Start Guide

Translated Text Here
Translated Text Here
Translated Text Here
Translated Text Here

For Proof Only
Dell Confidential

1 Connect the power adapter and press the power button

Connect the power adapter and press the power button
Connect the power adapter and press the power button
Connect the power adapter and press the power button
Connect the power adapter and press the power button



2 Finish Windows setup

Finish Windows setup | Finish Windows setup
Finish Windows setup | Finish Windows setup



Enable security
Enable security
Enable security
Enable security


3 Configure Wireless (optional)

Configure Wireless (optional) | Configure Wireless (optional)
Configure Wireless (optional) | Configure Wireless (optional)



4 Connect to a network

Connect to a network | Connect to a network
Connect to a network | Connect to a network



Touch Settings → Wireless icon → Select your network, and touch Connect.

Touch Settings → Wireless icon → Select your network, and touch Connect.

Touch Settings → Wireless icon → Select your network, and touch Connect.

Touch Settings → Wireless icon → Select your network, and touch Connect.

Touch Settings → Wireless icon → Select your network, and touch Connect.

NOTE: You may have to activate your network service before connecting.

NOTE: You may have to activate your network service before connecting.

NOTE: You may have to activate your network service before connecting.

NOTE: You may have to activate your network service before connecting.

NOTE: You may have to activate your network service before connecting.

5 Explore resources

Explore resources | Explore resources
Explore resources | Explore resources



Help and Tips
Help and Tips | Help and Tips
Help and Tips | Help and Tips



My Dell
My Dell | My Dell
My Dell | My Dell



Dell Shop
Dell Shop | Dell Shop
Dell Shop | Dell Shop

Product support

Product support | Product support
Product support | Product support

Contact Dell

Contact Dell | Contact Dell
Contact Dell | Contact Dell

Regulatory and safety

Regulatory and safety | Regulatory and safety
Regulatory and safety | Regulatory and safety

Computer model

Computer model | Computer model
Computer model | Computer model

Regulatory model and type

Regulatory model and type
Regulatory model and type
Regulatory model and type
Regulatory model and type

Información para NOM, o Norma Oficial Mexicana

La información que se proporciona a continuación se mostrará en los dispositivos que se describen en este documento, en conformidad con los requisitos de la Norma Oficial Mexicana (NOM):

Importador:

Dell México S.A. de C.V.
Paseo de la Reforma 2620 - Piso 11.º
Col. Lomas Altas
11950 México, D.F.

Número de modelo reglamentario:	T07G
Voltaje de entrada:	100 VAC–240 VAC
Corriente de entrada (máxima):	1,00 A ~ 1,30 A
Frecuencia de entrada:	50 Hz–60 Hz
Corriente de salida:	1,2 A / 1,54 A
Voltaje de salida	19,5 VDC



dell.com/support

dell.com/contactdell


dell.com/regulatory_compliance

Inspiron 3137
Inspiron 3137 series

T07G
T07G001


Features

Features | Features | Features | Features



Stylus (optional)

Stylus (optional) | Stylus (optional) | Stylus (optional) | Stylus (optional)



1. speakers
2. camera LED
3. front camera
4. microphones
5. microphone
6. power LED
7. power button
8. right speaker
9. microphone
10. Noble security lock slot
11. memory card reader
12. micro USB power connector
13. mini HDMI connector

1. speakers
2. camera LED
3. front camera
4. microphones
5. microphone
6. power LED
7. power button
8. right speaker
9. microphone
10. Noble security lock slot
11. memory card reader
12. micro USB power connector
13. mini HDMI connector

14. rear camera
15. security card reader (optional)
16. finger print reader (optional)
17. dock pins
18. docking guide slot
19. docking connector
20. USB 3.0 connector
21. left speaker
22. volume button
23. audio connector
24. Ambient Light Sensor
25. Pen Tip (replaceable)
26. Programmable buttons

14. rear camera
15. security card reader (optional)
16. finger print reader (optional)
17. dock pins
18. docking guide slot
19. docking connector
20. USB 3.0 connector
21. left speaker
22. volume button
23. audio connector
24. Ambient Light Sensor
25. Pen Tip (replaceable)
26. Programmable buttons

1. speakers
2. camera LED
3. front camera
4. microphones
5. microphone
6. power LED
7. power button
8. right speaker
9. microphone
10. Noble security lock slot
11. memory card reader
12. micro USB power connector
13. mini HDMI connector

1. speakers
2. camera LED
3. front camera
4. microphones
5. microphone
6. power LED
7. power button
8. right speaker
9. microphone
10. Noble security lock slot
11. memory card reader
12. micro USB power connector
13. mini HDMI connector

14. rear camera
15. security card reader (optional)
16. finger print reader (optional)
17. dock pins
18. docking guide slot
19. docking connector
20. USB 3.0 connector
21. left speaker
22. volume button
23. audio connector
24. Ambient Light Sensor
25. Pen Tip (replaceable)
26. Programmable buttons

14. rear camera
15. security card reader (optional)
16. finger print reader (optional)
17. dock pins
18. docking guide slot
19. docking connector
20. USB 3.0 connector
21. left speaker
22. volume button
23. audio connector
24. Ambient Light Sensor
25. Pen Tip (replaceable)
26. Programmable buttons

1. speakers
2. camera LED
3. front camera
4. microphones
5. microphone
6. power LED
7. power button
8. right speaker
9. microphone
10. Noble security lock slot
11. memory card reader
12. micro USB power connector
13. mini HDMI connector

14. rear camera
 15. security card reader (optional)
 16. finger print reader (optional)
 17. dock pins
 18. docking guide slot
 19. docking connector
 20. USB 3.0 connector
 21. left speaker
 22. volume button
 23. audio connector
 24. Ambient Light Sensor
 25. Pen Tip (replaceable)
 26. Programmable buttons
- NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.
- NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.
- NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.
- NOTE:** It is recommended that you immediately backup the operating system

14. rear camera
15. security card reader (optional)
16. finger print reader (optional)
17. dock pins
18. docking guide slot
19. docking connector
20. USB 3.0 connector
21. left speaker
22. volume button
23. audio connector
24. Ambient Light Sensor
25. Pen Tip (replaceable)
26. Programmable buttons

14. rear camera
 15. security card reader (optional)
 16. finger print reader (optional)
 17. dock pins
 18. docking guide slot
 19. docking connector
 20. USB 3.0 connector
 21. left speaker
 22. volume button
 23. audio connector
 24. Ambient Light Sensor
 25. Pen Tip (replaceable)
 26. Programmable buttons
- NOTE:** It is recommended that you immediately backup the operating system image using the USB device through Dell Backup and Recovery (DBAR) application.