


4. Internal Photograph of the Host

Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)




Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)




Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)

WLAN Main & Bluetooth Antenna




Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)



Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)

WLAN Aux. Antenna



Host: Notebook Computer (Brand Name: TOSHIBA / Model Name: Satellite W30t-A; Satellite W30Dt-A; Satellite Click; Toshiba Click)

