

Photographs

Figure 1
CD-RW DRIVE, M/N: LXR-40122A
General Appearance (CD-RW DRIVE 、Data Cable*2EA 、Power Adapter*3EA)



Figure 2
CD-RW DRIVE, M/N: LXR-40122A
General Appearance (Front & Left-Side View)



Figure 3
CD-RW DRIVE, M/N: LXR-40122A
General Appearance (Bottom & Side View)



Figure 4
CD-RW DRIVE, M/N: LXR-40122A
General Appearance (Rear View)



Figure 5
CD-RW DRIVE, M/N: LXR-40122A
General Appearance (Right-Side View)



Figure 6
CD-RW DRIVE, M/N: LXR-40122A
Internal View (Open the Top Cover)

