

Figure 17  
CD-RW DRIVE, M/N: LXR-40122B  
General Appearance (Front & Left-Side View)



Figure 18  
CD-RW DRIVE, M/N: LXR-40122B  
Appearance (Front & Right-Side View)




Figure 19  
CD-RW DRIVE, M/N: LXR-40122B  
General Appearance (Bottom & Side View)



Figure 20  
CD-RW DRIVE, M/N: LXR-40122B  
Appearance (Product Label)




Figure 21  
CD-RW DRIVE, M/N: LXR-40122B  
Appearance (Rear View)



Figure 22  
CD-RW DRIVE, M/N: LXR-40122B  
Internal View (Open the Top Cove)

