


Wireless Keyboard and Keypad with Nano Receiver

Model: LS6600R

PRODUCT GUIDE



CAUTION: To use this product properly, please read the user's guide before installation

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.


1

Installing the batteries

Step 1: Take the battery cover off.

Step 2: Insert the batteries as shown inside the battery compartment.

Step 3: Replace the cover.



**Warning:

- *Please insert the batteries with the correct position according to the instruction labeled in the Keyboard / Keypad.
- *The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

Battery warning statement:

Do not mix old and new batteries


Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.

Setup the Connection between the Receiver and the Keyboard, Keypad

1. Insert the batteries into the Keyboard & Keypad, then follow the steps below.


2. Take the nano receiver out from the keypad.


3. Plug the Nano receiver into the USB port of your computer.




- If the keypad or keyboard is not working, please put them into pairing mode.
- 5. Pairing: Re-plug the receiver into the USB port of your computer, then press the connect button on the bottom of the keyboard and keypad. If the keypad or keyboard does not work after 10 seconds, pair them again. (The receiver has auto pairing function).
- 6. The LED indicator on the keypad & Keyboard bright when it is in pairing mode and LED off when it is successfully paired with the receiver.
- 7. When the batteries' power of the keyboard or the keypad is low, the Low Power indicator bright.

*Keyboard, Keypad Indicator







Red LED Bright for 10 sec.
Pairing (LED OFF when paired or failed after 10 sec.)

2