


折線

正面



**Wireless Mouse
with Nano Receiver**

Model: ONA12HO127

PRODUCT GUIDE

CAUTION: To use this product properly, please read the user's guide before installation

**Federal Communication Commission
Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

1

反面

Mouse Button




1. Left button	6. LED Indicator
2. Right button	7. Nano Receiver
3. Scrolling Wheel	8. Battery Cover
4. Backward	9. Connect Button
5. Forward	10. OFF/ON Switch

Forward
Press this button to view the next page of the Internet browser.

Backward
Press this button to view the previous page of the Internet browser.

Installing the batteries
Step 1: Take the battery cover off.
Step 2: Insert the batteries as shown inside the battery compartment.
Step 3: Replace the cover.
Step 4: Turn on power switch.




****Warning:**

- *Please insert the batteries with the correct position according to the instruction labeled in the mouse.
- *The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

Battery warning statement:
Do not mix old and new batteries
Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.


Setup the Connection between the Receiver and the Mouse

1. Plug the Nano receiver into the USB port of your computer.



2. Insert the batteries into the mouse, then follow the steps below.
3. If the mouse is not working, please put it into pairing mode.
4. Pairing: Re-plug the Nano receiver into the USB port of your computer. If the mouse does not work after 10 seconds, then press the connect Button on the bottom of mouse again. (Nano receiver has auto pairing function).

During pairing



LED Indicator	Red LED on 3 Sec.
	Power On
	Red LED on 10 Sec.
	Connected NG
	Red LED OFF
	Connected OK
	Red LED Blinking
	Low Battery

折線