onn.

Wireless Vertical Mouse

Model: 100012595

PRODUCT GUIDE

BATTERY WARNING STATEMENT
Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.

Walmart Inc.,
Bentonville, AR 72716

Need help?
We're here for you every day from 7 a.m. – 9 p.m. CST.
Give us a call at 1-888-516-2630

We 'd love to hear from you. Scan with your Walmart app and let us know what you think.

6 811311 30945 5

Functional Introduction

1. Left button	6. DPI Switch Key
2. Right button	7. Nano Receiver
3. Scrolling wheel	8. Battery Cover
4. Forward	9. Connect Button
5. Backward	10. OFF/ON Switch

Forward
Press this button to view the next page in your Internet browser.
Backward
Press this button to view the previous page in your Internet browser.
DPI Switch Key (Five different DPI)
a) 5 adjustable DPI-The blink on key indicates the DPI setting in use

DPI	Blink
600 dpi	1
1000 dpi	2
1600 dpi	3
2400 dpi	4
3600 dpi	5

b) Default is 1600 DPI

Installing the batteries

Step 1: Take the battery cover off.
Step 2: Insert the battery as shown inside the battery compartment.
**Step 3:** Replace the cover.
**Warning:
*Please insert the battery with the correct position according to the instruction labeled on the mouse.

1

AA Battery

Setup the Connection between the Receiver and the Mouse

1. Insert the battery into the mouse, then follow the steps below.
2. In the meantime, to open the mouse under the cover, take the nano receiver out.
3. Plug the Nano receiver into the USB port on your computer.

4. If the mouse does not work, please put it into pairing mode.
5. Pairing: Re-plug the receiver into the USB port on your computer, then press the connect button on the mouse. If the mouse does not work after 10 seconds, pair them again. Keep the mouse closer to the receiver while in pairing mode.

LED Indicator

Green LED is on for 10 Sec.
Power On

Green LED Blinking for 10 Sec.
Low Battery Warning

Green LED Blinking
Pairing (LED OFF when paired or failed after 10 sec.)

2