

4.6 Photos of Radiation Measuring Setup

Test Mode: WIFI & FULL SYSTEM WORKING MODE (Signal Mode)



Test Mode: CHARGE & Operation MODE (Desktop type:WP-C424A)



Test Mode: CHARGE & Operation MODE (Wall-mounted type:WP-C424A)



5.6 Photos of Conduction Measuring Setup

Test Mode: CHARGE & Operation MODE(Desktop type:WP-C424A)



Test Mode: CHARGE & Operation MODE(Wall-mounted type:WP-C424A)

