
For Intel CPU


WNC Antenna




Main




Page 41 Rev. 00







Page 42 Rev. 00

Aux







Page 43 Rev. 00




Yageo Antenna




Main




Page 45 Rev. 00



Aux



Page 46 Rev. 00




Battery

For L09M3Z14




For L09M6Y14



Page 55 Rev. 00

For L09S3Z14



Page 56 Rev. 00