




System Transmit Path



Transmit antenna ports	Receive Antenna Ports	Receive Div. Antenna Ports
------------------------	-----------------------	----------------------------



Transmit signal in from Radio in RBS 800 MHz 900 MHz
Transmit signal out to Antenna



Transmit Signals out from Radios