

		GE Lighting A SAVANT COMPANY REVIEWED DATE: _____ SIGNATURE: _____ <input type="checkbox"/> Proof Reading - Spelling <input type="checkbox"/> Website Graphics Printability <input type="checkbox"/> Proof against TDS request <input type="checkbox"/> Website Graphics Printability	GRAPHICS APPROVAL Approvals designate all items on checked and have been reviewed & are correct in addition to other organizational responsibilities.	SKU LISTING INFO: 93131476 NPI CYNc Sam's reveal RS Con LED Zpk 7302489 REVISION (DATE) PK: 4 (04-20-23) CN BAK CODE 3PKL: <input type="checkbox"/> 100% NO HWK <input type="checkbox"/> 80% NO HWK <input type="checkbox"/> N/A INSERT (IF SHARED): None SUPPLIER PROJECT: N/A PRINT METHOD: <input type="checkbox"/> Offset/Litho <input type="checkbox"/> Flexo (direct) GE DIE: DL-90859 PK (VERSION): PK-00119101-1
			<input type="checkbox"/> PMS Cool Gray 11C	

PC93131476 ING

THIS ART IS SUPPLIED AT 100% SCALE
DO NOT RESIZE, RESHAPE OR ALTER

Recessed Downlight Installation Guide

Getting Started

Download the CYNc App, powered by Savant

Determine location and complete installation

Add your Recessed Downlight to the CYNc App

Set up your Amazon Alexa voice assistant (optional)

For set up help, visit cyncsupport.gelighting.com or call 1-844-302-2943

Let's Do It

Included:

Integrated Light Fixture

Flip Clips

You'll need:

Safety Glasses

Phillips Head Screwdriver

Ladder

Needle Nose Pliers (optional)

Specifications

Model	Input Voltage (Vac, Hz)	Current (mA)	Wattage (W)
Full Color RS Can 4" CTD85C8CRVD	120	10	15

Dimming Capability

NOT FOR USE WITH DIMMER SWITCHES.
Compatible with only CYNc smart dimmers that provide dimming of the switch or through the CYNc App.

Before you begin: Read these instructions completely and carefully.

WARNING: RISK OF ELECTRIC SHOCK

Risk of fire or electric shock. Read this kit only in businesses that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

Do not make or alter any open holes in an enclosure or wiring or electrical components during kit installation.

Prepare Electrical Wiring

ELECTRICAL REQUIREMENTS
The LED downlights must be supplied with 120VAC 60Hz.

GROUNDING INSTRUCTIONS
The grounding and bonding of the overall system shall be done in accordance with National Electrical Code (NEC) Article 409 and local codes.

GE is a trademark of General Electric Company. Used under trademark license. Amazon, Alexa, and the Alexa logo are trademarks of Amazon.com, Inc. or its affiliates. Google and other related marks and logos are trademarks of Google LLC.

Recessed Downlight Installation Guide

You Got This!

And we're here to help. For in-depth instructional videos and a guided tour through the installation, go to: cyncsupport.gelighting.com or call 1-844-302-2943

BEFORE YOU DO ANYTHING: Step 1
Turn Off The Power!

Turn off power at the source to the recessed housing(s) that you are installing the fixture(s) in.

Turn off power at the source to the recessed housing(s) that you are installing the fixture(s) in.

1. Housing with torsion bracket. Use the manufacturer installed torsion springs for installation.

Step 2
Remove Existing Trim and Bulb

Remove existing trim and bulb, revealing the housing and the existing socket inside.

Remove existing trim and bulb, revealing the housing and the existing socket inside.

2. Housing without torsion bracket. Replace the torsion springs with the flip clips included in the packaging using a screwdriver.

Step 3

Determine the Mounting Method

The Recessed Downlight is designed to install in most 6 in. and 5 in. recessed can fixtures. Use either the torsion spring or flip clip.

torsion bracket

Recessed Downlight Installation Guide

Step 4

Installing the Base

Medium Base Sockets
Screw the medium (E26) base into the socket and then connect the base to the fixture using the plug connector.

Medium Base Sockets

Plug-In Connection
Insert the plug connector from the ceiling into the plug connector on the fixture.

Plug-In Connection

Step 5

Finish Installation

1. Housing with torsion bracket. Check that the "torsion springs" are firmly attached. Compress the torsion springs and insert into the bracket inside the housing. Release springs and gently push up until flush with the ceiling.

Housing with torsion bracket

2. Housing without torsion bracket. Check that the "flip clips" are firmly attached. Center the fixture in the housing opening and gently push up until flush with the ceiling.

Housing without torsion bracket

Congratulations!

You've completed the Recessed Downlight installation.

Next...

- Download the CYNc App

Add your Recessed Downlight to the CYNc App

Set up your Amazon Alexa or Hey Google voice assistant (optional)

Enable Your Voice Assistant

Connect to your Amazon Alexa or Hey Google voice assistants in the CYNc App. Then try this:

Alexa, turn off the living room. *Hey Google, turn on the lights.*
 Alexa, turn on the bedroom. *Hey Google, good morning.*
 Alexa, set kitchen to 50%. *Hey Google, I'm leaving.*

GE is a trademark of General Electric Company. Used under trademark license. Amazon, Alexa, and the Alexa logo are trademarks of Amazon.com, Inc. or its affiliates. Google and other related marks and logos are trademarks of Google LLC.

Recessed Downlight Installation Guide

Additional Information and Warnings

FCC Compliance Statement Compliance Notice:
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
 However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information:
Caution: To maintain compliance with the FCC's RF exposure guidelines, please the product at least 20cm from nearby persons.

IC Statement
 This device complies with RSS247 of Industry Canada. Cet appareil se conforme à RSS247 de Canada d'Industrie.
 This device complies with Industry Canada license-exempt RSS standard(s).
 Operation is subject to the following two conditions:
 (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Appareil radio exempt de licence.
 Son fonctionnement est sujet aux deux conditions suivantes:
 (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) le dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.
 This equipment complies with IC RSS-302 radiation exposure limits set forth for an uncontrolled environment.
 This transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.
 Cet équipement est conforme aux limites d'exposition aux rayonnements IC RSS-302 définies pour un environnement non contrôlé.
 Cet émetteur doit être installé pour fournir une distance de séparation d'au moins 20 cm de toutes les personnes et ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou émetteur.

Like your new Recessed Downlight? Share your experience!
 Leave a review where you purchased the product.

★★★★★

PK-00119101-1