

FIGURE 3
DOWNLIGHT (CFIXRSCR6CRVD)
COVER REMOVE




FIGURE 4
DOWNLIGHT (CFIXRSCR6CRVD)
LED FRONT



FIGURE 5
DOWNLIGHT (CFIXRSCR6CRVD)
LED BACK




FIGURE 6
DOWNLIGHT (CFIXRSCR6CRVD)
MAINBOARD FRONT




FIGURE 7
DOWNLIGHT (CFIXRSCR6CRVD)
MAINBOARD BACK




FIGURE 8
DOWNLIGHT (CFIXRSCR6CRVD)
RF BOARD

