

Jiangsu Huitong(Group) Co., Ltd.

Remote Control User's Manual

1. Remote control model: YKF497-B001, YKF497-B002

2. Bluetooth connection:

2.1 Pairing

Press and hold the stop button first, then press the nozzle retract and nozzle extend buttons successively. When these three keys are pressed successively, RC will enter scanning mode.

2.2 The white LED on the top of the RC is on for 3s after the pairing is successful.



2.3 Product declaration:

This BLE remote control use the maximum communication rate=1Mbps, and the 2Mbps rate supported by the chip is not turned on.

3. Fuction list

Symbol	Name
\equiv	Menu
	Add/delete device
1 2	Activates User Profile Set user profiles via remote controll or app (App: Menu – Settings – Shower function)
P	Activates Full Flush
P	Activates Eco Flush
0	Activates Rearwash If Rearwash is not stopped, it automatically ends after 2 minutes
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Activates Ladywash If Ladywash is not stopped, it automatically ends after 2 minutes
B	Activates Warm Air Dryer If warm air dryer is not stopped, it automatically ends after 5 minutes
	Adjusts Water Temperature Water temperature can be set to the levels off, low, medium, high Settings are indicated on the remote controll (LED) and in the app (App: Menu – Settings – Shower function)
	Adjusts Water Spray Intensity Water spray intensity can be set to the levels low, medium, high Settings are indicated on the remote controll (LED) and in the app (App: Menu - Settings - Shower function)
cec	Adjusts Spray Wand Position Spray wand position can be set to the levels 1, 2, 3, 4, 5 Settings are indicated on the remote controll (LED) and in the app (App: Menu – Settings – Shower function)
Ь	Open/Close Lid
	Stops the running programme

4. Charge the remote control



Charging port: Type C

Requirements for charging adapter: satisfy with the charging protocol: PD、QC、AFC、FCP、SCP、Super VOOC、PE、Flash

Charge、APPLE 2.4A

5. This appliance contains batteries that are non-replaceable.

WARNING:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Remark:

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;

Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.