



CF76 Open Battery Cover



CF76 Disassembly Step 1




CF76 Disassembly Step 2




CF76 Antenna Disassembly



CF76 Disassembly Step 3



CF76 Disassembly Step 4



CF76 Disassembly Step 5