



EF81 open battery cover



EF81 disassembly step 1 (back part)




EF81 disassembly step 1 (front part)



EF81 disassembly step 2 (back part)




EF81 disassembly step 3 (back part)



EF81 Main PCB and Card PCB (Back part)






EF81 Main PCB and Card PCB (Front part)




EF81 Main PCB and Card PCB removed shieldings (Back part)




EF81 Main PCB and Card PCB removed shieldings (Front part)




Main Flex, Camera Flex and Topkey Flex (Back view)



Main Flex, Camera Flex and Topkey Flex (Front view)



GSM/UMTS antenna and BT antenna inside housing



GSM/UMTS antenna