



## Appendix D. Product Photos and Test Setup Photos

Antenna Location :







Front View




Back View




Direct Laptop Plug-in for USB Configuration 1  
(Horizontal Up with Phantom 5 mm Gap)



USB Cable Plug-in for USB Configuration 2  
(Horizontal Down with Phantom 5 mm Gap)



Direct Laptop Plug-in for USB Configuration 3  
(Vertical Front with Phantom 5 mm Gap)




USB Cable Plug-in USB Configuration 4  
(Vertical Back with Phantom 5 mm Gap)




Front View




Back View




Direct Laptop Plug-in for USB Configuration 1  
(Horizontal Up with Phantom 5 mm Gap and Flip 90)




USB Cable Plug-in for USB Configuration 2  
(Horizontal Down with Phantom 5 mm Gap and Flip 90)



Direct Laptop Plug-in for USB Configuration 3  
(Vertical Front with Phantom 5 mm Gap and Flip 90)



USB Cable Plug-in for USB Configuration 4  
(Vertical Back with Phantom 5 mm Gap and Flip 90)




**USB Cable Plug-in for USB Configuration 5  
(Tip Mode with Phantom 5 mm Gap and Flip 90)**




Front View



Back View




Direct Laptop Plug-in for USB Configuration 1  
(Horizontal Up with Phantom 5 mm Gap and Flip 180)




USB Cable Plug-in for USB Configuration 2  
(Horizontal Down with Phantom 5 mm Gap and Flip 180)



Direct Laptop Plug-in for USB Configuration 3  
(Vertical Front with Phantom 5 mm Gap and Flip 180)



USB Cable Plug-in USB Configuration 4  
(Vertical Back with Phantom 5 mm Gap and Flip 180)



**USB Cable Plug-in for USB Configuration 5  
(Tip Mode with Phantom 5 mm Gap and Flip 180)**