


PHOTOGRAPHS OF THE TEST CONFIGURATION

Set UUT as Master mode (Radar injected into Master)



Set UUT as Client mode (Radar injected into Master)

