

Device basics



- 1 Charging/Notification light
- 2 Nano SIM/Memory card slot
- 3 NFC
- 4 Volume/Zoom key
- 5 Fingerprint sensor
- 6 Power key
- 7 Wireless charging coil
- 8 Camera key
- 9 USB port/Charger/Audio adapter

To insert a nano SIM card and a memory card



- Do not cut your SIM card, as this may damage your device.
- 1 Drag out the SIM card tray.
- 2 Place the SIM card securely in the SIM card tray, as shown in the illustration.
- 3 Place the memory card securely in the tray, in the correct orientation as shown in the illustration.
- 4 Gently push the SIM card tray back into the slot until it fits into place.

To turn on your device

- It is recommended to charge the battery for at least 30 minutes before you turn on your device for the first time. It is important to use the USB Type-C™ cable provided when charging your device, as other types of USB cables can damage your device.
- 1 Press and hold down the power key until the device vibrates.
- 2 Wait a moment for the device to start.

To activate the screen

• Briefly press the power key.

Screen protection

Before using your device, remove all protection films to
enable full functionality.

Screen covers and protectors may help you protect your device against damage. We recommend you use only those screen covers intended for your Xperia™ device. The use of third party screen protection accessories may prevent your device from working correctly by covering sensors, lenses, speakers, or microphones and can invalidate the warranty.

Support for you

Use the Support app to find your device's model name, software information, help topics and support tools. Visit *support.sonymobile.com* from the Support app or any browser for user guides, troubleshooting tips, support forum and support contact information.

 You can find support contact information in the Support app even without a network connection. The Support app is not available in all countries and regions.

To access the Support app

Find and tap 2.

Warranty, SAR and usage guidelines

For information about warranty, SAR (Specific Absorption Rate) and safety guidelines, please read the Important information provided under Settings > System > About phone > Legal information on your device.

Transferring contacts and content

For transferring contacts, messages, photos or other data from an old device to your new device, we recommend that you use the Xperia Transfer Mobile application. On your new device you will find it in Settings > System. Visit https://www.sonymobile.com/xperiatransfer for more information.

To view the CE marking and the FCC ID

SONY®



1 Drag out the SIM card tray.

2 Drag out the label strip in the same way. To see the full text of the EU declaration of conformity, visit: http:// www.compliance.sony.de/.

To view the regulatory compliance mark

• Open the phone dialer, then enter *#07#.

To view the IMEI number

• Open the phone dialer, then enter *#06#.

Legal information

Publication number: 1315-6902.1

Problemation number: 131-3902.1 This Startup guide is published by Sony Mobile Communications Inc. or its local affiliated company, without any waranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications Inc. at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.

See regulatory information such as the device CE marking in the relevant label tray in the device. All product and company names mentioned herein are the trademarks or registered trademarks of their respective womers. Any rights not expressly granted herein are reserved. Visit https:// www.sonymobile.com/global-en/legal/ for more information.

Manufacturer: Som Mobile Communications Inc., 4-12:-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002, Japan: For EU product compliance: Sony Belgium, bijkantoor van Sony Europe Limited, Da Vinciana 7-Di, 1935 Zaventem, Belgium.

© 2018 Sony Mobile Communications Inc. All rights reserved.

Supported frequency bands

Some frequency bands might be turned off in certain markets or by certain operators. You can find your model number under Settings > System > About phone. H#416

UNTS HSPA+ (Bands 1, 2, 4, 5, 6, 8, 19) GSM GPR5/EDGE 850, 900, 1800, 1900 LTE (Bands 1, 2, 3, 4, 5, 7, 8, 12, 13, 17, 19, 20, 26, 28, 29, 32, 38, 39, 40, 41, 46, 66) WLAN, 24.6/5G, NFC GSM 850/900 - Power (Dass 4, DcS/B00/PCG1900) : Power (Dass 1, UNTS : Power (Dass 3, LTE : Power Class 3, 24.GHz-100mW, 515-5.35GHz-200mW, 5.47-5.725GHz-200mW, 5.735-5.835GHz-25mW, NFC 13.56MHz Startup guide



This product's battery charging system is certified by the California Energy Commission, as indicated by the BC logo.





Printed in XXX (Printers logotype)