


XPERIA 10 III

SONY

1 SIM




XQ-BT52




SIM1

SIM2

microSD



2 PWR ON





Startup guide

- Ръководство „Бърз старт“
- Úvodní příručka
- Kurzanleitung
- Installationsvejledning
- Alustusjuhend
- Guia de inicio
- Aloitusopas
- Guide de démarrage
- Οδηγός εκκίνησης
- Priručnik
- Használatbavételi útmutató
- Ræsihandbók
- Guida introduttiva
- Paleisties vadovas
- Sākšanas ceļvedis
- Opstartgids
- Oppstartsveiviser
- Instrukcja obsługi
- Manual de Iniciação
- Ghid de pornire
- Starthandbok
- Vodič za začetek uporabe
- Úvodná príručka
- Руководство по запуску
- Бастапқы нұсқаулық
- คู่มือเริ่มต้นการใช้งาน
- 用戶指南




Xperia Transfer 2




OR



https://rd1.sony.net/help/mobile/xperia-10m3/h_zz/



NFC



XQ-BT52



Printed in XXX (Printers logotype)

