


Introduction

Charging made easy

The Fast Charger **UCH32** reduces the charging time for Xperia™ devices that support the USB Power Delivery. Using the Fast Charger, you can quickly charge an Xperia™ smartphone.

- ! When charging a device with the Fast Charger **UCH32**, always use the **UCB24 USB Type-C™** cable that was included with the charger at purchase.



- 1 Charger unit
- 2 **UCB24 USB Type-C™** cable


Operating temperature

5°C to 35°C

Using the Fast Charger

Charging

To charge your device using the Fast Charger



- 1 Plug the **USB Type-C™** connector into the **USB Type-C™** port of your device.
- 2 Plug the USB connector at the other end of the cable into the charger.
- 3 Plug the charger into a power outlet. Your device battery then starts to charge.
- 4 When your device is fully charged, unplug the charger from the power outlet and disconnect the cable from your device by pulling it straight outwards. Make sure not to bend the connector.