



1. External Photograph of EUT

Brand Name: SONY / Type Name: PM-0631-BV





Brand Name: SONY / Type Name: PM-0631-BV





Brand Name: SONY / Type Name: PM-0631-BV





Brand Name: SONY / Type Name: PM-0631-BV



Brand Name: SONY / Type Name: PM-0631-BV





2. **Photograph of Accessory**

Brand Name: SONY / Type Name: PM-0631-BV

Specification of Accessory		
AC Adapter	Brand Name	Sony
	Model Name	EP800
Car Charger	Brand Name	Sony
	Model Name	AN400
Battery	Brand Name	Sony
	Model Name	Charles
Earphone 1	Brand Name	Sony
	Model Name	MH410c
	Type Name	AG-1103
Earphone 2	Brand Name	Sony
	Model Name	MH410c
	Type Name	AG-1100
USB Cable 1	Brand Name	Sony
	Model Name	EC450
USB Cable 2	Brand Name	Sony
	Model Name	EC300

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: SONY / Type Name: PM-0631-BV




Brand Name: SONY / Type Name: PM-0631-BV

AC Adapter



Brand Name: SONY / Type Name: PM-0631-BV



Brand Name: SONY / Type Name: PM-0631-BV



Brand Name: SONY / Type Name: PM-0631-BV

Car Charger



Brand Name: SONY / Type Name: PM-0631-BV

Earphone



Brand Name: SONY / Type Name: PM-0631-BV

USB Cable 1



Brand Name: SONY / Type Name: PM-0631-BV

USB Cable 2

