

1. External Photograph of EUT

Brand Name: Sony



Brand Name: Sony





2. Photograph of Accessory


Brand Name: Sony

| Specification of Accessory | | |
|----------------------------|------------|-------------|
| AC Adapter | Brand Name | Sony |
| | Model Name | UCH20 |
| | Type Name | AC-0060-US |
| Car Charger | Brand Name | Sony |
| | Model Name | AN400 |
| | Type Name | AC-0110-DC |
| Battery | Brand Name | Sony |
| | Model Name | LIS1594ERPC |
| | Type Name | N/A |
| Earphone 1 | Brand Name | Sony |
| | Model Name | MH410c |
| | Type Name | AG-1100 |
| Earphone 2 | Brand Name | Sony |
| | Model Name | MH410c |
| | Type Name | AG-1103 |
| USB Cable | Brand Name | Sony |
| | Model Name | UCB16 |
| | Type Name | AI-0142 |

Remark: For accessories equipped with this EUT, please refer to the following photos.



Brand Name: Sony



Brand Name: Sony

Adapter



Brand Name: Sony

Car charger



Brand Name: Sony

Battery



Brand Name: Sony

