



HBH-200 Bluetooth™ Handsfree



User's Guide
User's Guide
User's Guide
User's Guide

Bluetooth™ Handsfree
HBH-200

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Sony Ericsson HBH-200

First edition (July 2003)
This manual is published by Sony Ericsson Mobile Communications AB, without any warranty, improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this manual.
All rights reserved.

©Sony Ericsson Mobile Communications AB, 2003

Publication number: LZT 108 6336 R1A

Some of the services in this manual are not supported by all networks. This also applies to the GSM International Emergency Number 112. Contact your network operator or service provider if you are in doubt whether you can use a particular service or not.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.

Introduction Introduction Introduction Introduction

HBH-200 Handsfree

The HBH-200 Handsfree can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profiles. This user's guide focuses on usage with a Sony Ericsson mobile phone.

HBH-200 Handsfree

The HBH-200 Handsfree can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profiles. This user's guide focuses on usage with a Sony Ericsson mobile phone.



HBH-200 Handsfree

The HBH-200 Handsfree can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profiles. This user's guide focuses on usage with a Sony Ericsson mobile phone.

HBH-200 Handsfree

The HBH-200 Handsfree can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profiles. This user's guide focuses on usage with a Sony Ericsson mobile phone.

Attach and wear Attach and wear Attach and wear Attach and wear



Icons Icons Icons Icons

	Battery status Battery status Battery status Battery status
	Bluetooth on Bluetooth on Bluetooth on Bluetooth on
	Bluetooth connection Bluetooth connection Bluetooth connection Bluetooth connection
	Silent Silent Silent Silent
	Ongoing call (flashing when connecting) Ongoing call (flashing when connecting) Ongoing call (flashing when connecting) Ongoing call (flashing when connecting)
	Missed or rejected call Missed or rejected call Missed or rejected call Missed or rejected call

	Answered call Answered call Answered call Answered call
	Dialled number Dialled number Dialled number Dialled number


Symbols Symbols Symbols Symbols

	Press and hold Press and hold Press and hold Press and hold
	Go to standby and On/Off Go to standby and On/Off Go to standby and On/Off Go to standby and On/Off
	Simultaneous press Simultaneous press Simultaneous press Simultaneous press
	Simultaneous press Simultaneous press Simultaneous press Simultaneous press

For internal use only
Version: PA7


Sony Ericsson

Buttons Buttons Buttons Buttons



Getting started Getting started Getting started Getting started

Charge the battery Charge the battery Charge the battery Charge the battery




Chargers
Chargers
Chargers
Chargers

CLA-11

CST-13

Add the handsfree to the phone Add the handsfree to the phone Add the handsfree to the phone Add the handsfree to the phone



Prepare the phone

When you add the handsfree to the list of devices in the phone (also called pairing), the handsfree will recognize the phone automatically when it is turned on.

Prepare your phone according to the phone's user documentation on adding a Bluetooth device. The handsfree passkey is 0000.

You only need to add the handsfree to the phone once. If you want to use the handsfree with a new device you need to add it to that device.

Prepare the phone

When you add the handsfree to the list of devices in the phone (also called pairing), the handsfree will recognize the phone automatically when it is turned on.

Prepare your phone according to the phone's user documentation on adding a Bluetooth device. The handsfree passkey is 0000.

You only need to add the handsfree to the phone once. If you want to use the handsfree with a new device you need to add it to that device.

Prepare the phone

When you add the handsfree to the list of devices in the phone (also called pairing), the handsfree will recognize the phone automatically when it is turned on.

Prepare your phone according to the phone's user documentation on adding a Bluetooth device. The handsfree passkey is 0000.

You only need to add the handsfree to the phone once. If you want to use the handsfree with a new device you need to add it to that device.


Prepare the phone

When you add the handsfree to the list of devices in the phone (also called pairing), the handsfree will recognize the phone automatically when it is turned on.

Prepare your phone according to the phone's user documentation on adding a Bluetooth device. The handsfree passkey is 0000.

You only need to add the handsfree to the phone once. If you want to use the handsfree with a new device you need to add it to that device.

Handsfree successfully added Handsfree successfully added Handsfree successfully added Handsfree successfully added




The handsfree is now added to the phone and is ready to use.

The handsfree is now added to the phone and is ready to use.

The handsfree is now added to the phone and is ready to use.

The handsfree is now added to the phone and is ready to use.


Performance range Performance range Performance range Performance range



Optimal performance
Optimal performance
Optimal performance
Optimal performance

Limited performance
Limited performance
Limited performance
Limited performance

Calling Calling Calling Calling




The name of the latest added phone will appear in the display when you turn the handsfree on.

The name of the latest added phone will appear in the display when you turn the handsfree off.

The name of the latest added phone will appear in the display when you turn the handsfree on.

The name of the latest added phone will appear in the display when you turn the handsfree off.

Off Off Off Off



You can always press to turn the handsfree off, even if you are using the menus, call list or other functions.

You can always press to turn the handsfree off, even if you are using the menus, call list or other functions.

You can always press to turn the handsfree off, even if you are using the menus, call list or other functions.

You can always press to turn the handsfree off, even if you are using the menus, call list or other functions.

Call list Call list Call list Call list


The HBH-200 supports the call list in the phone, and icons indicate dialled, answered or missed calls in the display. For more information, refer to the phone's user documentation. The call list function works with a number of phones, please see page 33 for details.

The HBH-200 supports the call list in the phone, and icons indicate dialled, answered or missed calls in the display. For more information, refer to the phone's user documentation. The call list function works with a number of phones, please see page 33 for details.

The HBH-200 supports the call list in the phone, and icons indicate dialled, answered or missed calls in the display. For more information, refer to the phone's user documentation. The call list function works with a number of phones, please see page 33 for details.

The HBH-200 supports the call list in the phone, and icons indicate dialled, answered or missed calls in the display. For more information, refer to the phone's user documentation. The call list function works with a number of phones, please see page 33 for details.

Access the call list Access the call list Access the call list Access the call list




www.SonyEricsson.com




Sony Ericsson Mobile Communications AB
SE-221 88 Lund, Sweden

LZT 1086336
Printed in Hungary

Make a call using the call list
 Make a call using the call list
 Make a call using the call list
 Make a call using the call list



Make a call using the phone's keypad
 Make a call using the phone's keypad
 Make a call using the phone's keypad
 Make a call using the phone's keypad



Voice commands
 Voice commands
 Voice commands
 Voice commands


Voice commands, such as dial, redial, answer and reject, can be very useful when you are using the handsfree. For more information on voice commands, refer to the phone's user documentation.

Voice commands, such as dial, redial, answer and reject, can be very useful when you are using the handsfree. For more information on voice commands, refer to the phone's user documentation.

Voice commands, such as dial, redial, answer and reject, can be very useful when you are using the handsfree. For more information on voice commands, refer to the phone's user documentation.

Voice commands, such as dial, redial, answer and reject, can be very useful when you are using the handsfree. For more information on voice commands, refer to the phone's user documentation.

Make a call using voice dialling
 Make a call using voice dialling
 Make a call using voice dialling
 Make a call using voice dialling




When voice dialling is activated, you can voice dial as you normally would with your phone.

When voice dialling is activated, you can voice dial as you normally would with your phone.

When voice dialling is activated, you can voice dial as you normally would with your phone.

When voice dialling is activated, you can voice dial as you normally would with your phone.


Answer a call
 Answer a call
 Answer a call
 Answer a call



Tip: You can always use to answer and end a call.

Tip: You can always use to answer and end a call.


End a call
 End a call
 End a call
 End a call



Tip: You can always use to answer and end a call.

Tip: You can always use to answer and end a call.

Reject an incoming call
 Reject an incoming call
 Reject an incoming call
 Reject an incoming call



Press to reset the missed call icon. If the call list is supported, you will then enter the call list.


Press to reset the missed call icon. If the call list is supported, you will then enter the call list.

Press to reset the missed call icon. If the call list is supported, you will then enter the call list.


Press to reset the missed call icon. If the call list is supported, you will then enter the call list.

Settings


Adjust the earpiece volume
 Adjust the earpiece volume
 Adjust the earpiece volume
 Adjust the earpiece volume




Mute the microphone
 Mute the microphone
 Mute the microphone
 Mute the microphone




Adjust the ring volume
 Adjust the ring volume
 Adjust the ring volume
 Adjust the ring volume




Select ring signal
 Select ring signal
 Select ring signal
 Select ring signal




Add HBH-200 to a new phone
 Add HBH-200 to a new phone
 Add HBH-200 to a new phone
 Add HBH-200 to a new phone




Make a master reset
 Make a master reset
 Make a master reset
 Make a master reset



Transfer sound from phone to headset
 Transfer sound from phone to headset
 Transfer sound from phone to headset
 Transfer sound from phone to headset



Troubleshooting



Not in range
 The handsfree and the phone might not be within range of each other. See page 7.

Not in range
 The handsfree and the phone might not be within range of each other. See page 7.

Not in range
 The handsfree and the phone might not be within range of each other. See page 7.

Not in range
 The handsfree and the phone might not be within range of each other. See page 7.

No connection to phone
 Make sure that the handsfree is charged and within range of the phone. The settings in the phone may not be correct. Check or redo the settings in the phone for adding a Bluetooth device.

No connection to phone
 Make sure that the handsfree is charged and within range of the phone. The settings in the phone may not be correct. Check or redo the settings in the phone for adding a Bluetooth device.

No connection to phone
 Make sure that the handsfree is charged and within range of the phone. The settings in the phone may not be correct. Check or redo the settings in the phone for adding a Bluetooth device.

No connection to phone
 Make sure that the handsfree is charged and within range of the phone. The settings in the phone may not be correct. Check or redo the settings in the phone for adding a Bluetooth device.

- | | |
|---|---|
| <ul style="list-style-type: none"> • Bluetooth specification 1.1 • Handsfree profile • Headset profile (no caller identification.) • Talk time up to: 3 hours • Standby time up to: 85 hours • Range up to: 10 metres • Call list function: T610, T616, T618, T68i, T68, T39, R520 | <ul style="list-style-type: none"> • Bluetooth specification 1.1 • Handsfree profile • Headset profile (no caller identification.) • Talk time up to: 3 hours • Standby time up to: 85 hours • Range up to: 10 metres • Call list function: T610, T616, T618, T68i, T68, T39, R520 |
|---|---|

- | | |
|---|---|
| <ul style="list-style-type: none"> • Bluetooth specification 1.1 • Handsfree profile • Headset profile (no caller identification.) • Talk time up to: 3 hours • Standby time up to: 85 hours • Range up to: 10 metres • Call list function: T610, T616, T618, T68i, T68, T39, R520 | <ul style="list-style-type: none"> • Bluetooth specification 1.1 • Handsfree profile • Headset profile (no caller identification.) • Talk time up to: 3 hours • Standby time up to: 85 hours • Range up to: 10 metres • Call list function: T610, T616, T618, T68i, T68, T39, R520 |
|---|---|

Declaration of conformity


We, Sony Ericsson Mobile Communications AB of Nya Vattentorget 221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type DDA-0001001

to which this declaration relates is in conformity with the appropriate standards EN 300 328, EN 301 489-17, EN 301 489-7 and EN 60950 following the provisions of Radio Equipment and Telecommunication Equipment directive 1995/5/EC with requirements covering EMC directive 89/336/EEC and Low Voltage directive 73/23/EEC.

Lund, July 2003



Ulf Persson, Head of Product Business Unit Accessories