

Calling using voice commands Voice commands can be useful when you are using the headset and the phone is not close at hand. For more information on voice commands, see your phone User guide.

To make a call using voice commands Press the call handling key briefly, wait for a beep and say your command.

Note: Make sure voice commands are enabled and recorded in your phone before you try to use them. Transferring sound

adset

*phone*See the phone User guide.

- To reset the headset

- Battery

To transfer the sound from the phone to the

headset
 During a call on the phone, press the call handling key briefly. The sound is transferred to the headset

To transfer the sound from the headset to the

Resetting the headset Reset the headset if it behaves unexpectedly.

Simultaneously press and hold down both volume keys until the headset beeps and flashes red and

and the reduced beeps and flashes red and green alternately.
Simultaneously press and hold down both volume keys until the headset turns off.
Pair the headset with the phone in the same way as you paired it the first time.

A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times. When the battery needs charging, the indicator light flashes red and you hear a low beep. If you do not charge the headset, it automatically turns off.

To check the battery status

Simultaneously press both volume keys briefly: • one green flash – the battery needs charging

two green flashes – the battery is medium full
three green flashes – the battery is fully charged

Attaching the strap

To attach the enclosed strap, see figure 6. Viewing regulatory information

To view the regulatory information, see figure 7.

Troubleshooting

No connection to the phone Make sure the headset is charged and within range of the phone. Check or redo the Bluetooth settings in the phone. Try to pair the headset again.

Unexpected behaviour · Reset the headset.


redial function


Redial does not work


If the call list in the phone is empty you cannot use the

Language 2

Sony Ericsson Mobile Communications AB SE-221 88 Lund, Sweden 1202-2042.1 Printed in XXXXX







Microphone Microphone

To adjust the ring volume When you are not engaged in a call, or while the phone is ringing, press a volume key

To adjust the speaker volumeDuring a call, press a volume key.

Calling using voice commands Voice commands can be useful when you are using the headset and the phone is not close at hand. For

more information on voice commands, see your

Language 4

To make a call using voice commands Press the call handling key briefly, wait for a beep and say your command.

Note: Make sure voice commands are enabled and recorded in your phone before you try to use them.

To transfer the sound from the phone to the

 During a call on the phone, press the call handling
 In the first The sound is transferred to the headset key briefly. The sound is transferred to the headse

To transfer the sound from the headset to the *phone*See the phone User guide.

Resetting the headset Reset the headset if it behaves unexpectedly.

Simultaneously press and hold down both volume keys until the headset beeps and flashes red and

and the reduced beeps and flashes red and green alternately.
Simultaneously press and hold down both volume keys until the headset turns off.
Pair the headset with the phone in the same way as you paired it the first time.

A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times. When the battery needs charging, the indicator light flashes red and you hear a low beep. If you do not charge the headset, it automatically turns off.

To check the battery status

Simultaneously press both volume keys briefly: • one green flash – the battery needs charging

two green flashes – the battery is medium full · three green flashes - the battery is fully charged

Attaching the strap

To attach the enclosed strap, see figure 6. Viewing regulatory information

To view the regulatory information, see figure 7.

Troubleshooting

No connection to the phone Make sure the headset is charged and within range of the phone. Check or redo the Bluetooth settings in the phone. Try to pair the headset again.

Unexpected behaviour · Reset the headset.

Redial does not work

If the call list in the phone is empty you cannot use the

Sony Ericsson Mobile Communications AB SE-221 88 Lund, Sweden 1202-2042.1 Printed in XXXXX

