User guide

English

Language

Language

Language

Sony Ericsson

 (ϕ)

6

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

Reorient or relocate the receiving antenna

that to which the receiver is connected.

Declaration of conformity for HBH-PV720

Ve, Sony Ericsson Mobile Communications AB of

declare under our sole responsibility that our product

Industry Canada Statement

Nya Vattentornet SE-221 88 Lund, Sweden

and (2) This device must accept any interference received, including interference that may cause undesired operation

Any change or modification not expressly approved by Sony Ericsson may void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from

Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with RSS-210 of Industry Canada.

English

The Bluetooth™ headset HBH-PV720 can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profile. This User guide focuses on use with a Sony Ericsson mobile phone.

Charging the headset

Before using the HBH-PV720 for the first time, charge it with, for example, the supplied charger or your phone charger, see figure 2. For compatible chargers, see figure 3.

Turning on and off the headset

To turn on the headset • Press the power key (see figure 1). The indicator light shows a steady green light (if the light is red, the headset needs charging). After 3 seconds, the light turns off and the headset stays on.

To turn off the headset

• Press and hold down the power key until the indicator light shows a steady green light (if the light is red, the headset needs charging). After 2 seconds, the light fades and the headset turns off.

Pairing the headset

Before you can use the headset it has to be paired once with your phone. After a successful pairing, the headset automatically connects to the phone when it is turned on and within range.

Note: When you put the headset in pairing mode, do not press the call handling key together with the power key.

To pair the headset with your phone

- 1. Turn on the Bluetooth function in the phone. For instructions, see the phone User guide. 2. Place the phone within 20 cm (8 inches) of the
- headset. 3. Turn on the headset. The first time you do so, the
- headset automatically enters pairing mode and tries to pair with your phone (auto pairing).

Note: If auto pairing is not supported by your phone, or not successful, follow the two first steps above and turn on the headset. Then add the headset to your phone as described in your phone User guide. The passcode is 0000.

To pair the headset with another phone

- 1. Turn on the Bluetooth function in the phone. For instructions, see the phone User guide.
- 2. Place the phone within 20 cm (8 inches) of the headset.
- 3. Turn off the headset if it is turned on. Press and hold down the power key until the indicator light flashes red and green alternately.
- 4. Press Yes when Add device? appears in the phone. If required, the passcode is 0000. The headset beeps and flashes green when successfully paired.

Putting on the headset

Slide the ear hook behind your ear and point the microphone toward your mouth. For left ear use, change the position of the ear hook as instructed in figure 4.

Calling

When you have paired the headset with your phone, you can make and receive calls as long as the headset is turned on.

Solid objects, walls and a greater distance than 5 metres (16.5 feet) can affect the sound quality negatively. For best performance, wear the headset and the phone on the same side of your body.

To make a call


Use the phone keys to dial the number as normal. The call is automatically activated in the headset.

To end a call


• Press the call handling key briefly.

Press the call handling key briefly.

- hear a short beep (after 2 seconds).
- To redial the last number
- Double-click the call handling key.
- To answer a second call
- Press the call handling key. The ongoing call is put on hold.







5



 $(\mathbf{0})$

۲



First time charging: about 8 hours Normal charging: about 2 hours First time charging: about 8 hours Normal charging: about 2 hours



(3) (4)XXX XXX XX Regulatory information Regulatory information

Sony Ericsson type DDA-0002018 to which this declaration relates is in conformity with the appropriate standards EN 300 328:V1.7.1, EN 301 489-7:V1.3.1, EN 301 489-17:V1.2.1 and EN 60950-1:2006 following the provisions of Radio Equipment and Telecommunication Equipment directive **1999/5/EC**. Lund, May 2008

Jacob Sten, Head of Product Business Unit Accessories We fulfil the R&TTE Directive

We fulfil the R&TTE Directive. We fulfil the R&TTE Directive. We fulfil the R&TTE Directive. We fulfil the R&TTE Directive.

FC

€€0682

To answer a call

To reject a call

- Press and hold down the call handling key until you

headset

phone

Battery

 Press the power key briefly: • steady green light plus one green flash - the battery needs charging soon steady green light plus two green flashes - the

Press and hold down the call handling key until you hear a beep

To turn off the microphone (mute)

• Press both volume keys simultaneously. Mute is indicated with a beeping sound. Repeat to turn on the microphone again.

Adjusting volume

To adjust the ring volume • When you are not making a call, or when the phone is ringing, press a volume key.

To adjust the speaker volume

During a call, press a volume key.

Calling using voice commands

Voice commands can be useful when you are using the headset and the phone is not close to you. For more information on voice commands, see your phone User guide.

To make a call using voice commands

 Press the call handling key briefly, wait for a beep and say your command.

Note: Make sure voice commands are enabled and recorded in your phone before you use them.

Transferring sound

To transfer sound from the phone to the

• During a call, press the call handling key briefly. The sound is transferred to the headset

To transfer sound from the headset to the

See the phone User guide.

A new, or infrequently used, battery could have reduced capacity. It may need to be recharged a number of times.

When the battery needs charging, the indicator light flashes red and you hear a low beep. If you do not charge the headset, it automatically turns off.

To check the battery status

battery is half full steady green light plus three green flashes – the battery is fully charged

Resetting the headset

To reset the headset

Turn off the headset.

2. Press and hold down the power key until the

indicator light flashes red and green alternately 3. Press and hold down the power key and the call

handling key simultaneously until the headset turns off

4. Pair the headset with the phone in the same way as you paired it the first time.

Language 2

-

 \odot

Bluetooth[™] Headset HBH-PV720

Bluetooth

User guide User guide User guide User guide

1

Call handling

key Call handling

Volume kevs

Volume keys

Earspeaker

Earspeaker

Indicator light

Indicator light

Microphone

Microphone

Power key

Power key

key

-(•)

Sony Fricsson HBH-PV720

Sony Ericsson HBH-PV720 This User guide is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide. All rights reserved.

©Sony Ericsson Mobile Communications AB, 2008

Publication number: 1211-9294.1

Some of the services in this User guide are not supported by all networks. This also applies to the GSM International Emergency Number 112. Contact your network operator or service provider if you are in doubt whether you can use a particular service.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license. Sony and WALKMAN are trademarks or registered trademarks of Sony Corporation. Telefonaktiebolaget LM Ericsson.

H. F. This product is leadfree and halogenfree.



First time charging: about 8 hours Normal charging: about 2 hours First time charging: about 8 hours Normal charging: about 2 hours




Battery needs charging Battery needs charging



2





(4)

XXX XXX XX

Regulatory information

Regulatory information

Language 3

The Bluetooth[™] headset HBH-PV720 can be connected to any device with Bluetooth wireless technology that supports the handsfree or headset profile. This User guide focuses on use with a Sony Ericsson mobile phone.

Charging the headset

Before using the HBH-PV720 for the first time, charge it with, for example, the supplied charger or your phone charger, see figure 2. For compatible chargers, see figure 3.

Turning on and off the headset

To turn on the headset • Press the power key (see figure 1). The indicator light shows a steady green light (if the light is red, the headset needs charging). After 3 seconds, the light turns off and the headset stays on.

To turn off the headset

• Press and hold down the power key until the indicator light shows a steady green light (if the light is red, the headset needs charging). After 2 seconds, the light fades and the headset turns off.

Pairing the headset

Before you can use the headset it has to be paired once with your phone. After a successful pairing, the headset automatically connects to the phone when it is turned on and within range.

Note: When you put the headset in pairing mode, do not press the call handling key together with the power key.

To pair the headset with your phone

- 1. Turn on the Bluetooth function in the phone. For instructions, see the phone User guide. 2. Place the phone within 20 cm (8 inches) of the
- headset.
- 3. Turn on the headset. The first time you do so, the headset automatically enters pairing mode and tries to pair with your phone (auto pairing).

Note: If auto pairing is not supported by your phone, or not successful, follow the two first steps above and turn on the headset. Then add the headset to your phone as described in your phone User guide. The passcode is 0000.

To pair the headset with another phone

- 1. Turn on the Bluetooth function in the phone. For
- instructions, see the phone User guide. 2. Place the phone within 20 cm (8 inches) of the
- headset. 3. Turn off the headset if it is turned on. Press and hold down the power key until the indicator light flashes
- red and green alternately. 4. Press Yes when Add device? appears in the phone. If required, the passcode is 0000. The headset beeps and flashes green when successfully paired.

Putting on the headset

Slide the ear hook behind your ear and point the microphone toward your mouth. For left ear use, change the position of the ear hook as instructed in figure 4.

Calling

When you have paired the headset with your phone, you can make and receive calls as long as the headset is turned on.

Solid objects, walls and a greater distance than 5 metres (16.5 feet) can affect the sound quality negatively. For best performance, wear the headset and the phone on the same side of your body.

To make a call

Use the phone keys to dial the number as normal. The call is automatically activated in the headset.

To end a call

• Press the call handling key briefly.

To answer a call

Press the call handling key briefly.

To reject a call

- Press and hold down the call handling key until you hear a short beep (after 2 seconds).
- To redial the last number
- Double-click the call handling key.
- To answer a second call
- Press the call handling key. The ongoing call is put on hold.


Sony Fricsson Mobile Communications AB SE-221 88 Lund, Sweden 1211-9294.1


Printed in XXXXX

 (\bullet)



4





5

3

Press and hold down the call handling key until you hear a beep

To turn off the microphone (mute)

• Press both volume keys simultaneously. Mute is indicated with a beeping sound. Repeat to turn on the microphone again.

Adjusting volume

To adjust the ring volume • When you are not making a call, or when the phone is ringing, press a volume key.

To adjust the speaker volume

During a call, press a volume key.

Calling using voice commands

Voice commands can be useful when you are using the headset and the phone is not close to you. For more information on voice commands, see your phone User guide.

To make a call using voice commands

 Press the call handling key briefly, wait for a beep and say your command.

Note: Make sure voice commands are enabled and recorded in your phone before you use them.

Transferring sound

To transfer sound from the phone to the headset

• During a call, press the call handling key briefly. The sound is transferred to the headset

To transfer sound from the headset to the

phone See the phone User guide.

Battery

A new, or infrequently used, battery could have reduced capacity. It may need to be recharged a number of times.

When the battery needs charging, the indicator light flashes red and you hear a low beep. If you do not charge the headset, it automatically turns off.

To check the battery status

 Press the power key briefly: • steady green light plus one green flash - the battery needs charging soon steady green light plus two green flashes - the

battery is half full steady green light plus three green flashes – the battery is fully charged

Resetting the headset

To reset the headset

1. Turn off the headset.

2. Press and hold down the power key until the

indicator light flashes red and green alternately 3. Press and hold down the power key and the call

handling key simultaneously until the headset turns off

4. Pair the headset with the phone in the same way as you paired it the first time.

Language 4

-

 \odot