


### 3.2 Major chipset configuration

The following table shows platform configuration.

[Application chip] APQ8064-3

[Modem chip] MDM9215M

[RF IC] WTR1605L



Fusion 3 Overall Block Diagram

## 3 System Functionality

### 3.3 System startup

Fusion3 platform has two kinds of power up sources.

1. Pushing power key
2. USB cable plugging-in (device mode only)

### 3.4 System Power Down

After receiving power down request, it goes following procedure.

1. Disable SMPL function of PM8921
2. Set PS\_HOLD to Low.